



**DSEControl**



# **DEEP SEA ELECTRONICS**

## **DSEE050 Configuration Suite**

### **PC Software Manual**

**Document Number: 057-299**

Author: Anthony Manton





**Deep Sea Electronics Ltd.**

Highfield House  
Hunmanby  
North Yorkshire  
YO14 0PH  
ENGLAND

**Sales Tel:** +44 (0) 1723 890099

**E-mail:** [sales@deepseaelectronics.com](mailto:sales@deepseaelectronics.com)

**Website:** [www.deepseaelectronics.com](http://www.deepseaelectronics.com)

**DSEE050 Configuration Suite PC Software Manual**

© Deep Sea Electronics Ltd.

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder except in accordance with the provisions of the Copyright, Designs and Patents Act 1988.

Applications for the copyright holder's written permission to reproduce any part of this publication must be addressed to Deep Sea Electronics Ltd. at the address above.

The DSE logo and the names DSEGenset®, DSEAts®, DSEControl® and DSEPower® are UK registered trademarks of Deep Sea Electronics Ltd.

Any reference to trademarked product names used within this publication is owned by their respective companies.

Deep Sea Electronics Ltd. reserves the right to change the contents of this document without prior notice.

**Amendments Since Last Publication**

<b>Amd. No.</b>	<b>Comments</b>
1	Initial release
1.1	Added PCAN interface part number. Added 'alternative units' examples.
1.2	Corrected J1939-75 examples
1.3	Updated for E050 V1.1: Added SPN ignore list Added Theme Colour and Value Colour Added Speed Control Options Added Conversion of Unit Types Added additional selections for instrument and Icon types.
2	Added Min/Max speed control limits.

Typeface: The typeface used in this document is *Arial*. Care must be taken not to mistake the upper case letter I with the numeral 1. The numeral 1 has a top serif to avoid this confusion.

## TABLE OF CONTENTS

Section	Page
<b>1 INTRODUCTION.....</b>	<b>5</b>
1.1 CLARIFICATION OF NOTATION.....	5
1.2 GLOSSARY OF TERMS.....	6
1.3 BIBLIOGRAPHY .....	7
1.3.1 INSTALLATION INSTRUCTIONS.....	7
1.3.2 MANUALS .....	7
1.3.3 TRAINING GUIDES .....	7
<b>2 INSTALLATION AND USING DSE CONFIGURATION SUITE SOFTWARE .....</b>	<b>8</b>
2.1.1 USB-CAN INTERFACE.....	8
2.1.1.1 PCAN-USB CONNECTION DETAILS .....	8
2.1.1.2 USE WITH DSE CONFIGURATION SUITE PC SOFTWARE.....	8
2.1.2 READ CONFIGURATION .....	9
2.1.3 WRITE CONFIGURATION.....	10
2.1.4 TROUBLESHOOTING CONFIGURATION READ/WRITE .....	11
<b>3 EDITING THE CONFIGURATION .....</b>	<b>12</b>
3.1 SCREEN LAYOUT .....	12
3.2 MODULE .....	13
3.2.1 DISPLAY .....	13
3.2.2 POWER SAVING .....	13
3.2.3 START UP IMAGE .....	14
3.3 INPUTS.....	15
3.3.1 ANALOGUE INPUT CONFIGURATION .....	15
3.3.2 ANALOGUE INPUTS .....	15
3.3.2.1 FLEXIBLE SENSOR A, B, C, D.....	16
3.3.3 DIGITAL INPUTS .....	16
3.4 OUTPUTS.....	17
3.4.1 DIGITAL OUTPUTS .....	17
3.4.1.1 ANALOGUE INPUT .....	17
3.4.1.2 CAN INSTRUMENT .....	18
3.4.1.3 DM1 SIGNAL .....	19
3.4.1.4 SPN/FMI.....	19
3.4.2 VOLTAGE REFERENCE OUTPUT .....	19
3.5 CAN.....	20
3.5.1 CAN OPTIONS.....	20
3.5.2 CAN RECEIVE .....	21
3.5.2.1 CONVERSION OF UNIT TYPES.....	22
3.5.2.2 IMPORT AND EXPORT .....	22
3.5.2.3 SPNS USED .....	22
3.5.2.4 MESSAGE ID.....	23
3.5.2.4.1 STRUCTURE OF THE J1939 29-BIT MESSAGE ID .....	23
3.5.2.5 DATA STRUCTURE .....	24
3.5.2.6 DISPLAY .....	24
3.5.2.7 BUS VALUE AND MAPPED VALUE .....	25
3.5.2.8 ADDITIONAL EXAMPLES .....	25
3.5.2.8.1 ALTERNATIVE UNITS .....	25
3.5.2.8.2 PARAMETERS FROM ENGINE ECU.....	25
3.5.2.8.3 PARAMETERS FROM J1939-75 ENABLED GENERATOR CONTROLLER .....	26
3.5.3 CAN TRANSMIT.....	27
3.5.3.1 IMPORT AND EXPORT .....	27
3.5.3.2 MESSAGE.....	27
3.5.3.2.1 29-BIT CAN ID.....	28
3.5.3.3 FIXED DATA .....	28
3.5.3.4 FACTORY SETTINGS.....	28
3.5.3.5 ADDITIONAL EXAMPLES .....	29

3.5.3.5.1	29-BIT CAN ID.....	29
3.5.3.5.2	RATE AND FIXED DATA .....	29
3.5.4	SPEED CONTROL.....	30
3.5.4.1	OPTIONS .....	30
3.5.4.2	SPEED CONTROL .....	31
3.5.4.3	TSC1 MESSAGE CONFIGURATION .....	32
3.5.4.3.1	TSC1.....	33
<b>3.6</b>	<b>DISPLAY .....</b>	<b>34</b>
3.6.1	DISPLAY OPTIONS .....	34
3.6.2	THEME .....	35
3.6.3	INSTRUMENTATION.....	36
3.6.3.1	BITMAP MEMORY USAGE .....	36
3.6.3.2	TOOLBAR .....	37
3.6.3.3	CONFIGURING INSTRUMENT PARAMETERS .....	38
3.6.4	ICONS .....	41
3.6.4.1	DISPLAYS TOOLBAR .....	42
3.6.4.2	ICON BITMAPS .....	42
3.6.4.3	ICON INSTRUMENTATION.....	43
3.6.4.3.1	DTC .....	43
3.6.4.3.2	CAN INSTRUMENT .....	43
3.6.4.3.3	DIGITAL INPUT .....	44
3.6.4.3.4	DIGITAL OUTPUT .....	44
3.6.4.3.5	ANALOGUE INPUT .....	44
3.6.4.3.6	DM1 SIGNAL.....	45

## 1 INTRODUCTION

This document details the use of *DSE Configuration Suite PC Software* with the DSEE050 module, which is part of the DSEControl® range of products.

The manual forms part of the product and should be kept for the entire life of the product. If the product is passed or supplied to another party, ensure that this document is passed to them for reference purposes.

This is not a *controlled document*. DSE do not automatically inform on updates. Any future updates of this document are included on the DSE website at [www.deepseaelectronics.com](http://www.deepseaelectronics.com)




*DSE Configuration Suite PC Software* allows the DSEE050 module to be connected to a PC via USB to CAN interface. Once connected, the software allows easy, controlled access to various operating parameters within the module which can then be viewed and edited as required.

*DSE Configuration Suite PC Software* must only be used by competent, qualified personnel, as changes to the operation of the module may have safety implications on the engine to which it is fitted.

The information contained in this manual must be read in conjunction with the information contained in the appropriate module documentation. This manual only details what settings are available and how they may be used. Separate manuals deal with the operation of the individual module and its ancillaries, refer to section entitled *Bibliography* elsewhere in this document for further information.

### 1.1 CLARIFICATION OF NOTATION

Clarification of notation used within this publication.

 <b>NOTE:</b>	<b>Highlights an essential element of a procedure to ensure correctness.</b>
 <b>CAUTION!</b>	<b>Indicates a procedure or practice, which, if not strictly observed, could result in damage or destruction of equipment.</b>
 <b>WARNING!</b>	<b>Indicates a procedure or practice, which could result in injury to personnel or loss of life if not followed correctly.</b>

## 1.2 GLOSSARY OF TERMS

Term	Description
DSEExxx	All modules in the DSE 'E Series' (Engine Controller) range.
29-bit ID	29-bit Identifier used in the Extended J1939 header used by the DSEE050 device.
CAN	Controller Area Network Vehicle standard to allow digital devices to communicate to one another.
DEF	Diesel Exhaust Fluid A liquid used as a consumable in the SCR process to lower nitric oxide and nitrogen dioxide concentration in engine exhaust emissions.
DM1	Diagnostic Message 1 A DTC that is currently active on the engine ECU.
DM2	Diagnostic Message 2 A DTC that was previously active on the engine ECU and has been stored in the ECU's internal memory.
DPF	Diesel Particulate Filter A filter fitted to the exhaust of an engine to remove diesel particulate matter or soot from the exhaust gas.
DPTC	Diesel Particulate Temperature Controlled Filter A filter fitted to the exhaust of an engine to remove diesel particulate matter or soot from the exhaust gas which is temperature controlled.
DTC	Diagnostic Trouble Code The name for the entire fault code sent by an engine ECU.
ECU/ECM	Engine Control Unit/Management An electronic device that monitors engine parameters and regulates the fuelling.
FMI	Failure Mode Identifier A part of DTC that indicates the type of failure, e.g. high, low, open circuit etc.
HEST	High Exhaust System Temperature. Initiates when DPF filter is full in conjunction with an extra fuel injector in the exhaust system to burn off accumulated diesel particulate matter or soot.
HMI	Human Machine Interface A device that provides a control and visualisation interface between a human and a process or machine.
J1939	Refers to standard J1939 by the Society of Automotive Engineers.
OC	Occurrence Count A part of DTC that indicates the number of times that failure has occurred.
PGN	Parameter Group Number A CANbus address for a set of parameters that relate to the same topic and share the same transmission rate.
SCR	Selective Catalytic Reduction A process that uses DEF with the aid of a catalyst to convert nitric oxide and nitrogen dioxide into nitrogen and water to reduce engine exhaust emission.
SPN	Suspect Parameter Number A part of DTC that indicates what the failure is, e.g. oil pressure, coolant temperature, turbo pressure etc.

## 1.3 BIBLIOGRAPHY

This document refers to, and is referred by the following DSE publications which are obtained from the DSE website: [www.deepseaelectronics.com](http://www.deepseaelectronics.com) or by contacting DSE technical support: [support@deepseaelectronics.com](mailto:support@deepseaelectronics.com).

### 1.3.1 INSTALLATION INSTRUCTIONS

Installation instructions are supplied with the product in the box and are intended as a 'quick start' guide only.

DSE Part	Description
053-242	DSEE050 Installation Instructions

### 1.3.2 MANUALS

Product manuals are obtained from the DSE website: [www.deepseaelectronics.com](http://www.deepseaelectronics.com) or by contacting DSE technical support: [support@deepseaelectronics.com](mailto:support@deepseaelectronics.com).

DSE Part	Description
057-300	DSEE050 Operator Manual

### 1.3.3 TRAINING GUIDES

Training guides are provided as 'hand-out' sheets on specific subjects during training sessions and contain specific information regarding to that subject.

DSE Part	Description
056-117	J1939 29-bit ID

## 2 INSTALLATION AND USING DSE CONFIGURATION SUITE SOFTWARE

For information regarding installing and using *DSE Configuration Suite PC Software*, refer to DSE publication: **057-151 DSE Configuration Suite PC Software Installation & Operation Manual** which is found on the DSE website: [www.deepseaelectronics.com](http://www.deepseaelectronics.com)

### 2.1.1 USB-CAN INTERFACE

**NOTE:** DSE Stock and supply PCAN-USB IPEH-002021. DSE Part number 016-179. Contact [sales@deepseaelectronics.com](mailto:sales@deepseaelectronics.com).


To convert PC USB to CAN Interface, use one of the following devices. Both devices offer the same basic functionality, with the *Opto-Isolated* variant providing enhanced protection should there be a potential difference (up to 500 V) between the Earth points of the CAN device and the PC. The device driver is supplied with the interface and is further available at the website listed in the table below.

Manufacturer	Part Number	DSE Part Number	Description
PEAK-System Technik GmbH <a href="https://www.peak-system.com/">https://www.peak-system.com/</a>	IPEH-002021	016-179	PCAN-USB
	IPEH-002022	N/A	PCAN-USB Opto-Isolated

#### 2.1.1.1 PCAN-USB CONNECTION DETAILS


**NOTE:** Configuration CAN link requires 120  $\Omega$  termination resistor as per J1939 CAN standard. Termination resistor is fitted to DSE050 Configuration Harness (but not fitted to DSEE050 fully populated harness).

Connect PCAN-USB to DSEE050 using connections for CAN H, CAN L and GND. For suitable connection looms from DSE, see DSE Publication *057-300 DSEE050 Operator Manual*.



#### 2.1.1.2 USE WITH DSE CONFIGURATION SUITE PC SOFTWARE

Once installed, the device is selected within DSE Configuration Suite PC Software as follows:








## 2.1.2 READ CONFIGURATION

**NOTE:** During *Configuration Read* and *Configuration Write* operations, DSEE050 must be disconnected from the engine CAN link and connected only to PCAN-USB interface directly.

To read the existing configuration from the device:


- Connect via the CAN-USB interface as described in the section entitled *USB-CAN Interface*.
- Click  in the toolbar or select *File | Read from Module* or press *F5* on the computer keyboard.
- DSE Configuration Suite prompts to *Power Cycle* the module.
- Remove DC Power from the device.
- Wait a few seconds....
- Then reapply DC Power.
- Wait while the configuration is transferred. This takes a couple of minutes.
- During this time DSEE050 shows the *Bootloader* version number and an animation to show continuing progress.
- After *Validation*, DSE Configuration Suite confirms completion of the file transfer.
- Remove DC Power from the device.
- Wait a few seconds....
- Then reapply DC Power to apply the new configuration.




### 2.1.3 WRITE CONFIGURATION

**NOTE:** During *Configuration Read* and *Configuration Write* operations, DSEE050 must be disconnected from the engine CAN link and connected only to PCAN-USB interface directly.

To write the configuration to the device:

- Connect via the CAN-USB interface as described in the section entitled *USB-CAN Interface*.
- Click  in the toolbar or select *File | Write to Module* or press *F8* on the computer keyboard.
- Confirm to Write to the Module.
- DSE Configuration Suite prompts to *Power Cycle* the Module.
- Remove DC Power from the device.
- Wait a few seconds....
- Then reapply DC Power.
- Wait while the configuration is transferred. This takes a couple of minutes.
- During this time DSEE050 shows the *Bootloader* version number and an animation to show continuing progress.
- After *Validation*, DSE Configuration Suite confirms completion of the file transfer.
- Remove DC Power from the device.
- Wait a few seconds....
- Then reapply DC Power to apply the new configuration.




## 2.1.4 TROUBLESHOOTING CONFIGURATION READ/WRITE

Issue	Possible Solution
<i>PCAN-USB adaptor</i> is not available in the <i>Connect Via...</i> dropdown list box.	Try the following possible solutions in the order listed: <ul style="list-style-type: none"> <li>• Ensure PCAN-USB is connected to a functioning USB Port on the PC.</li> <li>• Disconnect and reconnect PCAN-USB device. Wait a few seconds, then try again to select <i>PCAN-USB adaptor</i>.</li> <li>• Close, DSE Configuration Suite PC Software. Ensure PCAN-USB Driver is correctly installed (use Windows Device Manager to check). Restart DSE Configuration Suite PC Software.</li> </ul>
<i>Please Connect and/or Select a Module</i> is displayed when attempting to read/write.	<ul style="list-style-type: none"> <li>• Ensure <i>PCAN-USB adaptor</i> is selected in the <i>Connect via</i> dropdown select box.</li> <li>• Ensure the cable between PCAN-USB and the DSEE050 is correctly connected.</li> <li>• Ensure the E050 is not additionally connected to the engine ECU.</li> </ul>
Transfer does not begin after power cycle of the DSEE050.	<ul style="list-style-type: none"> <li>• When requested to 'Toggle module power', remove DC Supply from DSEE050, ensure PCAN-USB is correctly connected to the DSEE050, then reapply DSE power to the DSEE050.</li> <li>• Ensure the E050 is not additionally connected to the engine ECU.</li> </ul>
<i>Communications Timeout</i> occurs during transfer.	<ul style="list-style-type: none"> <li>• Ensure the cable between PCAN-USB and the DSEE050 is correctly connected.</li> <li>• Ensure the E050 is not additionally connected to the engine ECU.</li> </ul>

### 3 EDITING THE CONFIGURATION


The software is broken down into separate sections to provide simple navigation while editing the module's configuration to suit an application.

#### 3.1 SCREEN LAYOUT




## 3.2 MODULE

### 3.2.1 DISPLAY




Parameter	Description
Brightness	<p><b>NOTE:</b> <i>Display Brightness</i> is also adjustable from the device fascia.</p> <p>Select the required brightness for the display backlight. Higher values allow the device to be viewed in bright ambient conditions, however this make it too bright if viewed at night time or in a darkened room.</p>

### 3.2.2 POWER SAVING



Parameter	Description
Enable	<p><input checked="" type="checkbox"/>: Power Saving is enabled. Upon extended period of CAN data inactivity, the device enters <i>Power Saving</i>. The device awakens when CAN data is received or when a device fascia button is pressed. This is useful for both power saving and to prevent attention being drawn to the device when the engine is no longer operating.</p> <p><input type="checkbox"/>: No Power Saving takes place.</p>
Timer	<p>Set the timer as required. After this period of user inactivity, the device enters <i>Power Saving</i> mode, reducing the DC power used and automatically disabling the screen when the engine stops, and CAN traffic is no longer received.</p>

### 3.2.3 START UP IMAGE




Parameter	Description
Show at Start Up	<input checked="" type="checkbox"/> : Image is shown at device power up. <input type="checkbox"/> : No image is shown.
Duration	Set the duration as required. At power up, the image is displayed for the configured duration.
Select Image	Click to browse the PC to select the required image. This image must be 320 pixels wide, 240 pixels high.

### 3.3 INPUTS

#### 3.3.1 ANALOGUE INPUT CONFIGURATION


This page is used to select the operation of the inputs. After selection, configuration is available on *Inputs | Analogue Inputs* or *Inputs | Digital Inputs*.



Parameter	Description
Analogue Input A, B, C, D	<p><b>Not Used:</b> The selected input is not used.</p> <p><b>Flexible Analogue:</b> The selected input is used as an analogue input. For example, this could be used to measure fuel level for inclusion on the device display.</p> <p><b>Digital:</b> The selected input is a digital input. For example, this input could be used to detect low fuel level from a switch located in the fuel tank.</p>

#### 3.3.2 ANALOGUE INPUTS

Inputs configured as *Flexible Analogue* are further configured here. Select the input to configure.



### 3.3.2.1 FLEXIBLE SENSOR A, B, C, D

**Sensor Description**

Sensor Name

**Input Type**

Parameter	Description
Input Type	Allows selection of Voltage, Current and Resistive input types with sub selections for Pressure, Temperature and Percentage (ie Level)

### 3.3.3 DIGITAL INPUTS

Inputs configured as *Digital* are further configured here.

**Analogue Input A (Digital)**

Close Configuration


Polarity

Parameter	Description
Close Configuration	<p><b>Close to Supply Negative:</b> Connect the input pin to Supply Negative to activate.</p> <p><b>Close to Supply Positive:</b> Connect the input pin to Supply Positive to activate.</p>
Polarity	<p><b>Close to Activate:</b> To activate the input, connect the input to the configured supply.</p> <p><b>Open to Activate:</b> To activate the input, disconnect the input from the configured supply (open circuit).</p>




### 3.4 OUTPUTS

This section is further divided into subsections.




#### 3.4.1 DIGITAL OUTPUTS



##### 3.4.1.1 ANALOGUE INPUT


Configures the output to operate upon the condition of a selected *Analogue Input*.



Parameter	Description
Polarity	<p><b>Energise:</b> The output becomes active when the input measurement is above the <i>Active</i> setting and remains active until the input measurement falls below the <i>Inactive</i> setting.</p> <p><b>De-Energise:</b> The output becomes inactive when the input measurement is above the <i>Active</i> setting and remains inactive until the input measurement falls below the <i>Inactive</i> setting.</p>
Active	<p><b>▲ NOTE:</b> Best practice is to include a small amount of <i>Hysteresis</i> (a gap between <i>Active</i> and <i>Inactive</i>) to prevent the output pulsating if the input value is <i>hovering</i> around the set point.</p> <p>Adjusts the value for the <i>Active</i> setting.</p>
Inactive	<p><b>▲ NOTE:</b> Best practice is to include a small amount of <i>Hysteresis</i> (a gap between <i>Active</i> and <i>Inactive</i>) to prevent the output toggling if the input value is <i>hovering</i> around the set point.</p> <p>Adjusts the value for the <i>Inactive</i> setting.</p>

### 3.4.1.2 CAN INSTRUMENT


Configures the output to operate upon the condition of a selected *CAN Instrument*.



Parameter	Description
Polarity	<p><b>Energise:</b> The output becomes active when the SPN value is above the <i>Active</i> setting and remains active until the SPN value falls below the <i>Inactive</i> setting.</p> <p><b>De-Energise:</b> The output becomes inactive when the SPN value is above the <i>Active</i> setting and remains inactive until the SPN value falls below the <i>Inactive</i> setting.</p>
Active	<p><b>▲ NOTE: Best practice is to include a small amount of Hysteresis (a gap between <i>Active</i> and <i>Inactive</i>) to prevent the output pulsating if the SPN value is <i>hovering</i> around the set point.</b></p> <p>Adjusts the value for the <i>Active</i> setting.</p>
Inactive	<p><b>▲ NOTE: Best practice is to include a small amount of Hysteresis (a gap between <i>Active</i> and <i>Inactive</i>) to prevent the output pulsating if the SPN value is <i>hovering</i> around the set point.</b></p> <p>Adjusts the value for the <i>Inactive</i> setting.</p>


### 3.4.1.3 DM1 SIGNAL

Configures the output to operate upon the condition of a selected *DM1 Signal*, often called *Indicator Lamps*.



Parameter	Description
Polarity	<b>Energise:</b> Output active when the selected signal is active. <b>De-Energise:</b> Output active when the selected signal is NOT active.

### 3.4.1.4 SPN/FMI



Parameter	Description
Polarity	<b>Energise:</b> Output active when the selected FMI is present for the selected SPN. <b>De-Energise:</b> Output active when the selected FMI is NOT present for the selected SPN.
SPN	Suspect Parameter Number to test.
FMI	Failure Mode Indicator to test for.


### 3.4.2 VOLTAGE REFERENCE OUTPUT

*Voltage Reference Output* is provided to supply external devices (sensors). Consult the device operator manual for specifications of this output.



### 3.5 CAN

This section is further divided into subsections.



#### 3.5.1 CAN OPTIONS



Parameter	Description
CAN Source Address	The Source Address (SA) that the TSC1 and DM3 (Clear DM2 DTCs) messages are sent from.
Baud Rate	Select the Baud Rate of the CAN interface to connect to (125 kbit/s, 250 kbit/s or 500 kbit/s)
Enable CAN Terminator Resistor	<p>A CAN network must be terminated at the extreme ends of the CAN cable. For full flexibility, DSEE050 has a switchable internal 120 Ω termination resistor.</p> <p><input type="checkbox"/>: Internal termination resistor is disabled. Useful for when the device is located 'in the middle' of the CAN network, and when a termination resistor is located elsewhere.</p> <p><input checked="" type="checkbox"/>: Internal termination resistor is enabled. Ensure the device is located 'at the end' of the CAN network and that an external termination resistor is not also fitted to 'this end' of the CAN network.</p>
SPN Ignore List	Provides a list of up to ten SPN/FMI combinations. DTCs present in the DM1 / DM2 messages are ignored and not displayed.

### 3.5.2 CAN RECEIVE

**NOTE:** For DSEE050 V1.1 and later, enter Pressure, Temperature, Volume and Speed SPNs as their 'base' units as described below. This allows DSE050 fascia editor to correctly convert and display the selected units.

**NOTE:** Factory settings assume J1939 *default priority* for the configured messages and *Source Address 00* for the transmitting device. For other values, amend the *CAN ID* as required.

Provides a flexible system for receiving and processes CAN messages with 29-bit Identifiers. Up to 100 (one hundred) SPNs are supported.

Factory settings (shown below) include a list of commonly required, predefined SPNs that may be changed, deleted, or added to by the system installer.

To reload Factory Settings, select *File | New | Exxx* then select the E050 configuration version relevant to your controller version. Write this configuration to the device to restore it to Factory Settings.


CAN Receive														
		Export		Import								Instruments used 24/100		
Instrumentation Configuration														
Message ID				Data Structure			Display		Bus Value		Mapped Value			
SPN	Description	CAN ID	Timeout (ms)	Byte	Bit	Length	D. Places	Suffix	Smallest	Largest	Smallest	Largest		
190	Engine Speed	0x18CF0040	5000	4	0	16	0	RPM	0	64255	0	8031		
110	Engine Coolant Temp	0x18FEEED0	5000	1	0	8	0	°C	0	250	-40	210		
174	Engine Fuel 1 Temp 1	0x18FEEED0	5000	2	0	8	0	°C	0	250	-40	210		
175	Engine Oil Temp 1	0x18FEEED0	5000	3	0	16	0	°C	0	64255	-273	1734		
94	Engine Fuel Delivery Pre...	0x18FEEF00	5000	1	0	8	0	kPa	0	250	0	1000		
100	Engine Oil Pressure	0x18FEEF00	5000	4	0	8	0	kPa	0	250	0	1000		
109	Coolant Pressure 1	0x18FEEF00	5000	7	0	8	0	kPa	0	250	0	500		
183	Engine Fuel Rate	0x18FEEF200	5000	1	0	16	1	l/h	0	64255	0	32127		
102	Engine Intake Manifold...	0x18FEEF600	5000	2	0	8	0	kPa	0	250	0	500		
106	Engine Intake Manifold...	0x18FEEF600	5000	3	0	8	0	°C	0	250	-40	210		
173	Engine Exhaust Tempera...	0x18FEEF600	5000	6	0	16	0	°C	0	64255	-273	1734		
168	Battery Potential/Power...	0x18FEEF700	5000	5	0	16	1	VDC	0	64255	0	32127		
158	Keyswitch Potential	0x18FEEF700	5000	7	0	16	1	VDC	0	64255	0	32127		
247	Engine Hours Total Oper...	0x18FEE6500	10000	1	0	32	0	h	0	2105409607	0	105277030		
3719	DPF1 Soot Percent	0x18FD7800	10000	1	0	8	0	%	0	250	0	250		
3720	DPF1 Ash Percent	0x18FD7800	10000	2	0	8	0	%	0	250	0	250		
3517	After Treatment 1 DEF L...	0x18FEE5600	5000	3	0	16	0	mm	0	64255	0	6425		
3688	HEST Lamp Command	0x18FD7C00	5000	7	2	3	0		0	7	0	7		
3697	DPF Lamp Command	0x18FD7C00	5000	1	0	3	0		0	7	0	7		
3703	DPF Inhibitor	0x18FD7C00	5000	3	2	2	0		0	3	0	3		
5245	DEF Low Level	0x18FEE5600	5000	5	5	3	0		0	7	0	7		
5246	SCR Inducement Severity	0x18FEE5600	5000	6	5	3	0		0	7	0	7		
623	Red Stop Lamp	0x18FEEC400	2500	1	4	2	0		0	3	0	3		
624	Amber Warning Lamp	0x18FEEC400	2500	1	2	2	0		0	3	0	3		
*														

### 3.5.2.1 CONVERSION OF UNIT TYPES

DSEE050 V1.1 and above allows user selection of certain unit types via the device fascia. To allow this to function correctly, *Suffixes* must be entered as listed below. Ensure the correct suffix is chosen to match the conversion as entered. For example, if the *Mapped Value* is chosen to convert to 'kilometres per hour', ensure *kph* is entered as the *Suffix*.

Instrument type	Required Suffix
Pressure	kPa PSI Bar
Temperature	°C °F °K
Speed	kph mph mps
Volume	L US gal m3
Flow	l/m gal/min m3/h
Torque	Nm lb/ft
Fuel Usage	km/l mpg(imp) mpg(us) mpg


### 3.5.2.2 IMPORT AND EXPORT



Allows *Instrumentation Configuration* to be saved to a file. This eases the function of copying the items to other projects.

Parameter	Description
Export	Exports the Instrumentation Configuration to a file.
Import	Imports Instrumentation Configuration items from a previously created file.

### 3.5.2.3 SPNS USED



Shows the usage of and remaining space for Configured SPNs

### 3.5.2.4 MESSAGE ID

**NOTE:** Message *Priority* forms part of the *Message ID*. Ensure to check the *Priority* of the message being sent by the CAN 'transmitting device' to allow correct configuration of the *Message ID*.

Describes the PGN and SPN to receive.

Parameter	Description
SPN	J1939 Suspect Parameter Number to display.
Description	Free text string to describe the instrument.
CAN ID	29-bit CAN Message Identifier to receive. <i>CAN ID</i> must match exactly the full ID of the message to be received in the standard J1939 29-bit (Extended) format.
Timeout (ms)	Should the specified message not be received for the duration of <i>Timeout</i> , an alarm is raised.

#### 3.5.2.4.1 STRUCTURE OF THE J1939 29-BIT MESSAGE ID

Byte 1	Byte 2	Byte 3	Byte 4
Priority, Data Page	PDU Format	PDU Specific	Source Address
8 bits (3 unused)	8 bits	8 bits	8 bits

#### Byte 1 – Priority and Data Page

Byte 1 is an 8-bit byte however three bits are unused.

Byte 1							
Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0
Not Used			Priority (0 to 7)			Reserved	Data Page

The following table is used to simplify determination of the value for Byte 1.

**NOTE:** *Data Page* is most commonly zero (0). However, ensure to check the documentation of the CAN transmitting device.

Priority	Value of Byte 1 when Data Page=0	Value of Byte 1 when Data Page=1
0	0x00 (0)	0x01 (1)
1	0x04 (4)	0x05 (5)
2	0x08 (8)	0x09 (9)
3	0x0c (12)	0x0d (13)
4	0x10 (16)	0x11 (17)
5	0x14 (20)	0x15 (21)
6	0x18 (24)	0x19 (25)
7	0x1c (28)	0x1d (29)

### **Byte 2 and Byte 3 – PDU Format and PDU Specific**

The *PDU Format* value details the specific or broadcast address. The interpretation of *PDU Specific* changes based on the *PDU Format* value:

- Where *PDU Format* is between 0x00 and 0xEF (0 and 239), the message is referred to as Peer-to-Peer (P2P), *PDU Specific* contains the destination address. The destination address is the device that is expected to act upon the message. Other devices may read the message but are not expected to act upon it.
- Where *PDU Format* is between 0xF0 and 0xFF (240 and 255), the message is referred to as a *Broadcast* message, intended to be received by any device. In this case, *PDU Format* and *PDU Specific* together indicate the parameter group.
- The PGN is the *Data Page*, *PDU Format* and *PDU Specific* together and is usually referred to in Hexadecimal.

### **Byte 4 - Source Address**

The *Source Address* is used to indicate the specific application on the network where the CAN message has been sent from. Every network application must have a unique ID (253 addresses are available (0 to 253)).

### **3.5.2.5 DATA STRUCTURE**


Details where in the 8 Byte data packet the specified SPN is to be found.

Parameter	Description
Byte	Byte number (1 to 7) where the SPN is found.
Bit	Which bit of the specified Byte that the SPN starts.
Length	Length of the data in bits.

### **3.5.2.6 DISPLAY**

Details where in the 8 Byte data packet the specified SPN is to be found.

Parameter	Description
D.Places	How many decimal places to include in the displayed value after the processing of the value according to <i>Bus Value</i> and <i>Mapped Value</i> settings.
Suffix	Free text entry of the <i>Suffix</i> (typically the units) of the display. This is displayed along with the instrumentation value. Example showing two instruments with <i>Suffix</i> of <i>kPa</i> and <i>°C</i>





### 3.5.2.7 BUS VALUE AND MAPPED VALUE

Parameter	Description
Bus Value Smallest Bus Value Largest	Details the smallest and largest values that are expected to be received in the CAN data.
Mapped Value Smallest Mapped Value Largest	Details how the Displayed Values relate to the received <i>Bus Values</i> . For example: <i>Bus Value</i> 0 to 240. <i>Mapped Value</i> -40 to 210.  This configures the device to display -40 when the value 0 is received and to display 210 when the value 240 is received. Values in between are linearly interpolated.

### 3.5.2.8 ADDITIONAL EXAMPLES

PGNs often requested to be received are listed in the following sections.

#### 3.5.2.8.1 ALTERNATIVE UNITS

Depending upon user preferences alternative units are sometimes required. The table below includes common SPNs with non-metric units.

Instrumentation Configuration												
Message ID				Data Structure			Display		Bus Value		Mapped Value	
SPN	Description	CAN ID	Time-out (ms)	Byte	Bit	Length	D.Places	Suffix	Smallest	Largest	Smallest	Largest
100	Oil Pressure	0x18FEEF00	5000	4	0	8	1	PSI	0	250	0	1450
110	Coolant Temp	0x18FEEE00	5000	1	0	8	0	°F	0	250	-40	410
174	Fuel Temp	0x18FEEE00	5000	2	0	8	0	°F	0	250	-40	410

#### 3.5.2.8.2 PARAMETERS FROM ENGINE ECU

 **NOTE:** The listed *CAN IDs* below assume *Message Priority 6* and transmitting *Source Address 00*. For other values, amend the *CAN ID* as required.

Instrumentation Configuration												
Message ID				Data Structure			Display		Bus Value		Mapped Value	
SPN	Description	CAN ID	Time-out (ms)	Byte	Bit	Length	D.Places	Suffix	Smallest	Largest	Smallest	Largest
987	Protect Lamp	0x18FECA00	2500	1	0	2	0		0	3	0	3
3038	Malfunction Lamp MIL	0x18FECA00	2500	1	6	2	0		0	3	0	3

### 3.5.2.8.3 PARAMETERS FROM J1939-75 ENABLED GENERATOR CONTROLLER

Where a suitably configured J1939-75 Generator Controller is available, commonly requested electrical parameters are listed below.

Such compatible controllers include DSE4510 MKII, DSE4520 MKII, DSE6110 MKIII, DSE6120 MKIII, DSE7310 MKII, DSE7320 MKII, DSE7410 MKII, DSE7420 MKII, DSE8610 MKII (This list is not exhaustive. Contact support@deepseaelectronics.com for a full list of supported DSE devices).

**NOTE:** The listed *CAN IDs* below assume *Message Priority 6* and transmitting *Source Address 44 (0x2c)* to match DSEgenset Factory (default) settings. For other values, amend the *CAN ID* as required.

Instrumentation Configuration												
Message ID				Data Structure			Display		Bus Value		Mapped Value	
SPN	Description	CAN ID	Time-out (ms)	Byte	Bit	Length	D.Places	Suffix	Small-est	Largest	Smallest	Largest
2440	Average L-L V	0x18FE062C	2500	1	0	16	0	V AC	0	65530	0	65530
2444	Average L-N V	0x18FE062C	2500	3	0	16	0	V AC	0	65530	0	65530
2436	Average Frequency	0x18FE062C	2500	5	0	16	0	Hz	0	9216	0	720
2448	Average Current	0x18FE062C	2500	7	0	16	0	A AC	0	65530	0	65530
2452	Total Real Power	0x18FE052C	2500	1	0	32	1	kW	0	2001200000	-20000000	12000
2456	Total Reactive Power	0x18FE042C	2500	1	0	32	1	kvar	0	2001200000	-20000000	12000
2460	Total Apparent Power	0x18FE052C	2500	5	0	32	1	kVA	0	2001200000	-20000000	12000
3567	Gen Not in Auto	0x18FD932C	2500	1	3	2	0		0	3	0	3
3545	Gen Breaker	0x18FD912C	2500	1	0	3	0		0	7	0	7

### 3.5.3 CAN TRANSMIT

Provides DSEE050 with a flexible system for transmitting up to 20 (twenty) CAN messages. This is provided to send fixed CAN messages for 'requesting' the ECU to transmit certain PGNs. One such example is Engine Running Hours. A corresponding entry in *CAN Receive* is required to receive and convert the SPNs within the requested PGN.

The screenshot shows the 'Instrumentation Configuration' window with a table of CAN messages. Callouts provide instructions: 'Click to select, then press Delete to delete an entry.' points to a checkmark in the 'Enabled' column; 'Click to add new entry.' points to an asterisk icon at the bottom of the table; 'Click to enable / disable the entry.' points to a checkmark in the 'Enabled' column.

Instrumentation Configuration					
Enabled	Message			Fixed Data	
	CAN ID	Rate (ms)	Bytes	Values	
<input checked="" type="checkbox"/>	0x18EA00EA	5000	3	E5:FE:00	
<input checked="" type="checkbox"/>	0x18EA00EA	5000	3	CB:FE:00	
<input checked="" type="checkbox"/>	0x18EA00EA	5000	3	7B:FD:00	
*					

#### 3.5.3.1 IMPORT AND EXPORT

Allows the Instrumentation Configuration to be saved to a file. This eases the function of copying the items to other projects.

Parameter	Description
Export	Exports the Instrumentation Configuration to a file.
Import	Imports Instrumentation Configuration items from a previously created file.

#### 3.5.3.2 MESSAGE

Describes the PGN and SPN to send.

Parameter	Description
CAN ID	<p><b>NOTE:</b> Source Address of the sending application (DSEE050) forms part of the Message <i>CAN ID</i>. Ensure to check the requirements of the receiving device (typically the Engine ECU) to ensure the Source Address used is compatible. For further details see section entitled <i>29-bit CAN ID</i> elsewhere in this document.</p> <p>29-bit CAN Message Identifier to send.</p>
Rate (ms)	The rate at which the message is cyclically sent.

### 3.5.3.2.1 29-BIT CAN ID

**NOTE:** *Source Address* of the sending application (DSEE050) forms part of the *29-bit CAN ID*. Ensure to check the requirements of the receiving device (typically the Engine ECU) to ensure the *Source Address* used is compatible.

The following CAN ID is used to request a PGN be sent by the ECU. As the engine ECU is *usually* *Source Address 00*, PDU Specific in the *Request* message is 00.

CAN ID	Description
0x18EA00EA	Priority 6, PDU Format 0xEA, PDU Specific 0x00. Source Address 0xEA (decimal 234).

### 3.5.3.3 FIXED DATA

Details the data packet sent to ECU when requesting a PGN be sent. Three bytes of data follow which detail the PGN being requested.

Parameter	Description
Bytes	Number of Data Bytes in the message.
Values	The data to send. This is the PGN being requested.

### 3.5.3.4 FACTORY SETTINGS

Factory Settings of DSEE050 include the following CAN Transmit entries to request PGNs be sent by the ECU.

PGN REQUESTED			Rate (ms)	Fixed Data	
				Bytes	Values
0xFD7B	AT1S	After Treatment 1 Service (DPF Soot and Ash Levels)	5000	3	7B FD 00
0xFECB	DM2	Diagnostic Message 2 (List of Previously Active DTCs)	5000	3	CB FE 00
0xFEE5	HOURS	Engine Hours, Revolutions	5000	3	E5 FE 00

### 3.5.3.5 ADDITIONAL EXAMPLES

PGNs often requested to be transmitted are listed below.

#### 3.5.3.5.1 29-BIT CAN ID

The following CAN ID is used to request a PGN be sent by the ECU. Three bytes of data follow which detail the PGN being requested.

CAN ID	Description
0x18EA00EA	Priority 6, PDU Format 0xEA, PDU Specific 0x00. Source Address 0xEA (decimal 234).

#### 3.5.3.5.2 RATE AND FIXED DATA


The following Rate, Bytes and Values must be entered to the *CAN Transmit* configuration to request the PGNs be sent.

PGN REQUESTED			Rate (ms)	Fixed Data	
				Bytes	Values
0xFEB3	LFII	Fuel Information (Liquid)	5000	3	B3 FE 00
0xFEE9	LFC1	Fuel Consumption (Liquid)	5000	3	E9 FE 00

### 3.5.4 SPEED CONTROL

**NOTE:** When enabled, speed control messages are sent using J1939 TSC1 (PGN 0) only. Alternative methods of speed control are not available.

#### 3.5.4.1 OPTIONS



Parameter	Description
J1939 Speed Enable	<input type="checkbox"/> : Speed control is disabled. All other options are 'greyed out' and are unavailable. <input checked="" type="checkbox"/> : Speed control is enabled. Review and configure the remaining Speed Control options.
Crank Disconnect Speed	TSC1 Speed Control messages are continuously sent to the engine ECU based upon the measured engine speed: <b>Engine Speed ≤ Crank Disconnect Speed:</b> TSC1 message includes the value of 0. <b>Engine Speed &gt; Crank Disconnect Speed:</b> TSC1 messages include the value for engine speed based upon <i>Default Speed</i> setting and any user applied adjustments (i.e. Speed Raise/Speed Lower controls).
Min Speed	Limits the minimum speed the engine is requested to run at. When adjusted lower than the configured <i>Crank Disconnect</i> value, the <i>Crank Disconnect</i> value is applied as the Min Speed.
Default Speed	Speed the engine is initially requested to run at.
Max Speed	Limits the maximum speed the engine is requested to run at.
Speed Step Size	The size of step changes when increasing or decreasing engine speed by fascia button pressed or external input activation.
CAN Receive Speed Data Message	Select the source of the CAN instrument used to indicate engine speed. Typically, this is from SPN 190 (EEC1 – Engine Speed).
TSC1 Message Transmit Rate	Transmit Rate of the TSC1 CAN message used to control engine speed.

### 3.5.4.2 SPEED CONTROL

The screenshot shows a configuration window titled "Speed Control". It contains five dropdown menus and a "Create..." button. The dropdown menus are: "Speed Control Source" (Buttons Only), "Speed up Source" (Not used), "Speed Down Source" (Not used), "Analogue Input" (Not used), and "Control Curve" (Not Used).

Parameter	Description
Speed Control Source	<p><b>Analogue Input:</b> Analogue input is the only method for Speed Control.</p> <p><b>Buttons Only:</b> Fascia buttons are the only method for Speed Control.</p> <p><b>Buttons or Digital Input:</b> Fascia buttons and/or Digital Input are both used for Speed Control.</p> <p><b>Digital Inputs Only:</b> Digital Inputs are the only method for Speed Control.</p> <p><b>Disabled:</b> Speed Control is disabled.</p>
Speed Up Source Speed Down Source	Selects which digital input is used for Speed Control (When <i>Speed Control Source</i> is configured to <i>Buttons or Digital Input or Digital Inputs Only</i> ).
Analogue Input	Selects which analogue input is used for Speed Control (When <i>Speed Control Source</i> is configured to <i>Analogue Input</i> .)
Control Curve	Allows mapping of a curve from the input value to RPM (When <i>Speed Control Source</i> is configured to <i>Analogue Input</i> .)

### 3.5.4.3 TSC1 MESSAGE CONFIGURATION

Parameter	Description
Engine Override Control Mode (SPN 695)	<p>The override control mode defines which sort of command is used:</p> <p><b>Override disabled:</b> Disable any existing control commanded by the source of this command.</p> <p><b>Speed control:</b> Govern speed to the included “desired speed” value.</p>
Engine Requested Speed Control Conditions (SPN696)	<p>This mode tells the engine control system the governor characteristics that are desired during speed control. The four characteristics defined are:</p> <p><b>Transient Optimized for driveline disengaged and non-lockup conditions:</b> This speed governor gain selection is adjusted to provide rapid transition between speed setpoints. RPM overshoot and undershoot may be greater than what is seen when the “speed control characteristic” is set to be stability optimized</p> <p><b>Stability Optimized for driveline disengaged and non-lockup conditions:</b> This control condition has been optimized to minimize rpm overshoot and undershoot given an expected plant consisting of the engine and its accessory loads. This gain adjustment is not intended to compensate for driveline characteristics. This characteristic is most appropriate when no driveline is connected</p> <p><b>Stability Optimized for driveline engaged and/or in lockup condition 1 (e.g., vehicle driveline):</b> This control condition has been optimized to minimize rpm overshoot and undershoot given a more complex plant. For instance, the more complex plant would contain the engine, its accessory loads and the driveline characteristics. As an example, the driveline characteristics might include the effective spring mass relationship of pumps, tires, clutches, axles, driveshafts, and multiple gear ratios. This characteristic is most appropriate when a driveline is engaged</p> <p><b>Stability Optimized for driveline engaged and/or in lockup condition 2 (e.g., PTO driveline):</b> This speed control characteristic is available for applications requiring compensation for more than one driveline characteristic. It has been optimized to minimize rpm overshoot and undershoot given a more complex plant of the second variety. This more complex plant would again contain the engine, its accessory loads and a second driveline characteristic unique from the one described in speed control characteristic.</p>



Parameter	Description
Override Control Mode Priority (SPN 897)	<p><b>Highest priority:</b> Used for situations that require immediate action by the receiving device in order to provide safe vehicle operation (i.e., braking systems). This level of priority should only be used in safety critical conditions</p> <p><b>High priority:</b> Used for control situations that require prompt action in order to provide safe vehicle operation. An example is when the transmission is performing a shift and requires control of the engine in order to control driveline reengagement.</p> <p><b>Medium priority:</b> Used for powertrain control operations which are related to assuring that the vehicle is in a stable operating condition. An example is when the traction control system is commanding the engine in order to achieve traction stability.</p> <p><b>Low priority:</b> Used to indicate that the associated command desires powertrain control but is needed for function which improves the driver comfort which may be overridden by other devices. An example is cruise control or the non-critical part of a transmission shift to a new gear.</p>
Transmit Rate (SPN 3349)	This parameter indicates the transmission rate at which the sending device transmits the TSC1 message. The engine adjusts its timeout for TSC1 messages accordingly.
Control Purpose (SPN 3350)	<p>State signal which indicates which control mode the sending device is using to generate the TSC1 command.</p> <p>Available options are:  <b>Accelerator Pedal/Operator Selection</b>  <b>Cruise Control</b>  <b>PTO Governor</b>  <b>Road Speed Governor</b>  <b>Engine Protection</b>  <b>Temporary Power Train Control (Original use of TSC1 Command)</b></p>
Counter and Checksum Enabled	<p><input type="checkbox"/>: Counter (SPN 4206) and Checksum (SPN 4207) are NOT included in the TSC1 message.</p> <p><input checked="" type="checkbox"/>: Counter (SPN 4206) and Checksum (SPN 4207) are included in the TSC1 message transmitted by the device.</p>

### 3.5.4.3.1 TSC1


The complete TSC1 Message is as follows.

PGN 0 (0x0000) – Transmitted from DSE050 to the engine ECU (when configured to do so).


SPN	Name	Pos'n	bits	Offset	Scaling
695	Engine Override Control Mode	Byte 0, bit 0	2	N/A	N/A
696	Engine Requested Speed Control Conditions	Byte 0, bit 2	2	N/A	N/A
897	Override Control Mode Priority	Byte 0, bit 4	2	N/A	N/A
898	Engine Requested Speed	Byte 1, bit 0	16	0	0.125 /bit
518	Engine Requested Torque	Byte 3, bit 0	8	-125	1 /bit
3349	TSC1 Transmission Rate	Byte 4, bit 0	3	N/A	N/A
3350	TSC1 Control Purpose	Byte 4, bit 3	5	N/A	N/A
4191	Engine Requested Torque High Resolution	Byte 5, bit 0	4	N/A	N/A
4206	Message Counter	Byte 7, bit 0	4	N/A	N/A
4207	Message Checksum	Byte 7, bit 4	4	N/A	N/A


### 3.6 DISPLAY

This section is further divided into subsections.




#### 3.6.1 DISPLAY OPTIONS



Parameter	Description
Display Screen Number on Module	<p>Where multiple instrumentation screens are configured, displaying the screen number may ease display navigation. The number appears at the bottom of the <i>Icons</i> display.</p> <p>Example  <b>1/2</b> means that there are two instrumentation displays available and the first one is being viewed.</p>
Display Engine Lamps on Module	<p>Displays the Malfunction Indicator Lamps (MIL) at the top of the <i>Icons</i> display area.                      This includes the lamps from the DM1 message for: <i>Red, Amber, Malfunction, Protect</i>. Their exact meaning depends upon the configuration of the device (typically the engine ECU) transmitting them.</p> <p>Example:  </p> <p>This shows the Shutdown Lamp active, with all other lamps inactive.</p>

### 3.6.2 THEME




Parameter	Description
Active Theme	<b>Light:</b> Display theme is lighter, optimised for viewing in bright ambient conditions. <b>Dark:</b> Display theme is darker, optimised for viewing in darker conditions such as in poorly lit engine rooms.
Theme Colour	Select the colour used for the meter displays.
Value Colour	Select the colour used for the display of values.


### 3.6.3 INSTRUMENTATION

Allows the Instrumentation display to be created/edited. Up to 30 (thirty) screens are supported.

Showing an *empty* editor before instrumentation is added.



Showing the editor with one instrumentation page added.
















#### 3.6.3.1 BITMAP MEMORY USAGE

Where required, the system installer selects bitmap images to provide a graphical description of the instrument. Each image occupies memory space.


This section shows the amount of memory (Bytes) currently utilised by and available for instrumentation *Bitmaps*.

### 3.6.3.2 TOOLBAR


Icon	Description
	<p>Click to select the type of instrumentation page to add.</p> <p>If there are no existing pages, the new page becomes Page 1. When instrumentation pages are already present, the new page is added between 'after' the currently viewed page.</p> <p><b>Single Instrument:</b> Single, large display instrument.</p> <p><b>Quad Instrument:</b> Four smaller instruments arranged in a 2 X 2 grid.</p> <p><b>Split Screen:</b> One full width, half height instrument arranged above four small digital instruments.</p> <p><b>Table View:</b> Five digital instruments arranged in a single column.</p> 
	<p>Deletes the current instrumentation screen (after confirmation).</p>
	<p>Moves the currently viewed page down one position in the instrumentation list.</p>
	<p>Moves the currently viewed page up one position in the instrumentation list.</p>
	<p>View the Next Instrumentation Page.</p>
	<p>View the Previous Instrumentation Page.</p>
	<p>Import a previously saved Instrumentation file.</p>
	<p>Save the current Instrumentation page layout and design to file. This is useful if the same instrumentation design is to be used in other device configurations.</p>
	<p>Add a new Single Instrumentation Page.</p>
	<p>Add a new Quad Instrumentation Page.</p>
	<p>Add a new Split Instrumentation Page.</p>
	<p>Add a new Table View Instrumentation Page.</p>


### 3.6.3.3 CONFIGURING INSTRUMENT PARAMETERS



The instrumentation page is blank upon first creating it.


Click  to add an instrument into the area reserved for it. This allows some areas to be kept blank, without an instrument if required.



Example





Area without an instrument. This appears *blank* on the device display. Click  if it's required to show an instrument in this place.





To configure a specific instrument, select the Page the instrument is located on (Next  and Previous ) and then click the instrument. *Properties* displays the instrument settings for viewing and configuration.



Parameter	Description
Type	Select the Instrument Type. <b>CAN Instrument:</b> The instrument is used to display the value or one of the configured SPNs received over CAN.. <b>Analogue Input:</b> The instrument is used to display the value of one of the device's analogue inputs. <b>Digital Input:</b> The instrument is used to display the state of one of the device's digital inputs. <b>Digital Output:</b> The instrument is used to display the state of one of the device's digital outputs. <b>Requested Speed:</b> The instrument is used to display the engine speed requested by the device in the outgoing TSC1 message.
SPN Available when <i>Type</i> is set to <i>CAN Instrument</i> .	To select the SPN used for the instrument, click the property line and then click  e.g.  Now select from the list of previously configured SPNs. SPNs are configured on the <i>CAN / CAN Receive</i> page of the configuration.

Editing the Configuration

<p>Input Available when <i>Type</i> is set to <i>Input</i>.</p>	<p>To select the SPN used for the instrument, click the property line, click  and select the input to use.</p> 
<p>Min. Value Available when <i>Type</i> is set to <i>CAN</i>, <i>Analogue input</i> and <i>Requested Speed</i>.</p>	<p>The minimum value to be displayed by the instrument. This cannot be lower than the minimum value of the Analogue Input / SPN selected.</p>
<p>Max. Value Available when <i>Type</i> is set to <i>CAN</i>, <i>Analogue input</i> and <i>Requested Speed</i>.</p>	<p>The maximum value to be displayed by the instrument. This cannot be higher than the maximum value of the Analogue Input / SPN selected.</p>
<p>Image Available when <i>Type</i> is set to <i>CAN</i>, <i>Analogue input</i> and <i>Requested Speed</i>.</p>	<p>Icon to use for the instrument.</p>
<p>On Image Off Image Available when <i>Type</i> is set to <i>Digital Input</i> or <i>Digital Output</i></p>	<p>Icon to use when the input/output is On (active) or Off (inactive)</p>


Parameter	Description
Image	<p><b>NOTE:</b> Several <i>Theme Specific</i> images are supplied within DSE Configuration Suite PC Software. Custom images are added using the option <i>User Supplied</i> as detailed below.</p> <p>Allows an image to be displayed for the instrument. To select an image, click the parameter line and then click </p>  <p><b>Theme Specific:</b> Select one of the predefined images from the currently selected <i>Theme</i>. Eg:</p>  <p>Example of displays with images added.</p>  <p><b>User Supplied:</b> Select a bitmap (bmp) image to display. <b>No Image:</b> No image is added to the instrument.</p>




### 3.6.4 ICONS

Allows the *Icons* display on the DSEE050 right hand side to be created/edited.











Showing an *empty* editor before any icons are added. Up to eight (8) are supported.



Showing the editor with one instrumentation page added.



### 3.6.4.1 DISPLAYS TOOLBAR

Icon	Description
	Click to add a new icon to the display area. Up to eight (8) are supported.
	Click to delete the currently selected icon from the display.
	Select the previous icon.
	Select the next icon.
	View the display mimic with all icons in their <i>Off</i> state.
	View the display mimic with all icons in their <i>On</i> state.
	View the display mimic with all icons in their <i>Slow Flash</i> (1 Hz) state.
	View the display mimic with all icons in their <i>Fast Flash</i> (2 Hz) state.
	Import a previously saved <i>Icons</i> file.
	Save the current <i>Icons</i> layout to file. This is useful if the same design is to be used in other device configurations.

### 3.6.4.2 ICON BITMAPS

This section is used to determine how the icon appears in the display area.

Parameter	Description
Off <input type="button" value="Select..."/>	Click <i>Select</i> to choose the image to display when this icon is <i>Off</i> . For example, this could be a <i>greyed-out</i> version of the <i>On</i> image or could simply be left <i>Blank</i> .
On/Flash On <input type="button" value="Select..."/>	Click <i>Select</i> to choose the image to display when this icon is <i>On</i> (including when flashing).
Flash Off <input type="button" value="Select..."/>	Click <i>Select</i> to choose the image to display when this icon is <i>Flashing Off</i> . For example, this could be a <i>greyed out</i> version of the <i>On</i> image or could simply be left <i>Blank</i> .
<input type="button" value="Bitmap Help"/>	Click <i>Bitmap Help</i> to display a reminder of the <i>Bitmap</i> requirements. <b>Image Format:</b> Microsoft Windows™ “.bmp” file. <b>Colour Depth:</b> 16 bits per pixel. <b>Max Size:</b> 62 pixels wide, 164 pixels high.  Click <i>OK</i> to close the reminder and return to the main editor.
Position X: <input type="text" value="11"/> Y: <input type="text" value="30"/>	Adjusts the position of the icon on the display. The display mimic is used to verify the screen is as desired.
Bitmap Memory Usage <input type="text" value="72102/1024000 (70%)"/>	Where required, the system installer selects bitmap images to provide a graphical description of alarms and operational status. Each image occupies memory space. This section shows the amount of memory (Bytes) currently utilised by and available for instrumentation <i>Bitmaps</i> .

### 3.6.4.3 ICON INSTRUMENTATION

This section is used to determine when the icon appears in the display area.

Parameter	Description
Type	Select the source to check to determine if the image is to be visible.  <b>DTC:</b> Selects a Diagnostic Trouble Code as the source for the icon visibility. <b>CAN Instrument:</b> Selects one of the defined <i>CAN Receive</i> items as the source for the icon visibility. Digital Input: Digital Output: Analogue Input: DM1 Signal:

#### 3.6.4.3.1 DTC

When *Icon Instrumentation Type* is configured to *DTC*, the following parameters are available. The system allows for up to four entries per icon. Where more than one entry is added, the icon is displayed should any one of the entries be true. i.e. the entries are considered as an OR condition.

Parameter	Description
Instrumentation	Select from the list of previously configured SPNs. The state of this SPN is used to determine icon visibility. SPNs are configured on the <i>CAN / CAN Receive</i> page of the configuration.
On	Determines when to display the selected <i>On/Flash On</i> icon.  <b>SPN:</b> Selects which SPN to test. <b>FMI:</b> Select the FMI to act upon.
Slow Flash	Determines when to <i>Slow Flash</i> (1 Hz) the selected icon.  <b>SPN:</b> Selects which SPN to test. <b>FMI:</b> Select the FMI to act upon.
Fast Flash	Determines when to <i>Fast Flash</i> (2 Hz) the selected icon.  <b>SPN:</b> Selects which SPN to test. <b>FMI:</b> Select the FMI to act upon.

#### 3.6.4.3.2 CAN INSTRUMENT

When *Icon Instrumentation Type* is configured to *DTC*, the following parameters are available. The system allows for up to four entries per icon. Where more than one entry is added, the icon is displayed should any one of the entries be true. i.e. the entries are considered as an OR condition.

Parameter	Description
Instrumentation	Select from the list of previously configured SPNs. The state of this SPN is used to determine icon visibility. SPNs are configured on the <i>CAN / CAN Receive</i> page of the configuration.
On	Determines when to display the selected <i>On/Flash On</i> icon.  <b>Condition:</b> Select what condition to test the SPN Value for. <b>Values:</b> Select the value to use with the <i>Condition</i> .  For example: Condition: Equal to (=). Value: 1 Action: The icon is visible when the SPN value is '1'.

Parameter	Description
Slow Flash	<p>Determines when to <i>Slow Flash</i> (1 Hz) the selected icon.</p> <p><b>Condition:</b> Select what condition to test the SPN Value for.  <b>Values:</b> Select the value to use with the <i>Condition</i>.</p> <p>For example:                      Condition: More Than (&gt;).                      Value: 128                      Action: The icon flashes slowly when the SPN value is more than '128'.</p>
Fast Flash	<p>Determines when to <i>Fast Flash</i> (2 Hz) the selected icon.</p> <p><b>Condition:</b> Select what condition to test the SPN Value for.  <b>Values:</b> Select the value to use with the <i>Condition</i>.</p> <p>For example:                      Condition: Between.                      Value: From 10 to 20.                      Action: The icon flashes rapidly when the SPN value is between '10' and '20'.</p>

### 3.6.4.3.3 DIGITAL INPUT

When *Icon Instrumentation Type* is configured to *Digital Input*, the following parameter is available.

Parameter	Description
Digital Input	<p>Select the device digital input.                      The icon visibility follows the state of the digital input.</p>

### 3.6.4.3.4 DIGITAL OUTPUT

When *Icon Instrumentation Type* is configured to *Digital Output*, the following parameter is available.

Parameter	Description
Digital Output	<p>Select the device digital output.                      The icon visibility follows the state of the digital output.</p>

### 3.6.4.3.5 ANALOGUE INPUT

When *Icon Instrumentation Type* is configured to *Analogue Input*, the following parameters are available.

Where more than one entry is added, the icon is displayed should any one of the entries be true. i.e. the entries are considered as an OR condition.

Parameter	Description
On	<p>Determines when to display the selected <i>On/Flash On</i> icon.</p> <p><b>Condition:</b> Select what condition to test the analogue input value for.  <b>Values:</b> Select the value to use with the <i>Condition</i>.</p> <p>For example:                      Condition: Equal to (=).                      Value: 1                      Action: The icon is visible when the SPN value is '1'.</p>

Parameter	Description
Slow Flash	<p>Determines when to <i>Slow Flash</i> (1 Hz) the selected icon.</p> <p><b>Condition:</b> Select what condition to test the analogue input value for.  <b>Values:</b> Select the value to use with the <i>Condition</i>.</p> <p>For example:                      Condition: More Than (&gt;).                      Value: 128                      Action: The icon flashes slowly when the analogue input value is more than '128'.</p>
Fast Flash	<p>Determines when to <i>Fast Flash</i> (2 Hz) the selected icon.</p> <p><b>Condition:</b> Select what condition to test the analogue input value for.  <b>Values:</b> Select the value to use with the <i>Condition</i>.</p> <p>For example:                      Condition: Between.                      Value: From 10 to 20.                      Action: The icon flashes rapidly when the analogue input value is between '10' and '20'.</p>

#### 3.6.4.3.6 DM1 SIGNAL

When *Icon Instrumentation Type* is configured to *DM1 Signal*, the following parameter is available.

Parameter	Description
DM1 Signal	<p>None: The icon does not appear.                      Amber: The icon appears when the Amber Warning Lamp (AWL) is on.                      Malfunction: The icon appears when the Malfunction Indicator Lamp (MiL) is on.                      Protect: The icon appears when the Protect Lamp is on.                      Red: The icon appears when the Red Stop Lamp (RSL) is on.</p>

*This Page Intentionally Blank*