



DSEControl



DEEP SEA ELECTRONICS PLC

DSEM840 Operator Manual

Document Number: 057-248

Author: Anthony Manton



Deep Sea Electronics Plc
Highfield House
Hunmanby
North Yorkshire
YO14 0PH
ENGLAND

Sales Tel: +44 (0) 1723 890099
Sales Fax: +44 (0) 1723 893303

E-mail: sales@deepseapl.com
Website: www.deepseapl.com

DSEM840 Operator Manual

© Deep Sea Electronics Plc

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder except in accordance with the provisions of the Copyright, Designs and Patents Act 1988.

Applications for the copyright holder's written permission to reproduce any part of this publication must be addressed to Deep Sea Electronics Plc at the address above.

The DSE logo and the name DSEControl® are UK registered trademarks of Deep Sea Electronics PLC.

Any reference to trademarked product names used within this publication is owned by their respective companies.

Deep Sea Electronics Plc reserves the right to change the contents of this document without prior notice.

Revision History

Issue No.	Comments
1	Initial release of document.
2	Added Manual Shutdown feature.
3	Added M840-02.
4	Added PWM outputs as available in M840-02 V4.1 onwards. Updated Connection list.
4.1	Updated Applicable Standards. Added CAN basic instructions to <i>Connecting to CODESYS</i> section.
4.2	Removed erroneous M835 mentions. Updated typo for Qxxx in Glossary. Added entry to Safety Instructions General. Added more details to Ignition specification (clarifying use for M840-01 persistent vars)
4.3	Added IOSTANDARD library to the Troubleshooting section. Updated Applicable Standards table. Added Network Variables Added 'unsupported' CODESYS visu elements

TABLE OF CONTENTS

Section	Page
1 INTRODUCTION	6
1.1 CLARIFICATION OF NOTATION	7
1.2 GLOSSARY OF TERMS	7
1.3 RELATED INFORMATION	8
1.3.1 TECHNICAL INFORMATION	8
1.4 SAFETY INSTRUCTIONS	9
1.4.1 GENERAL	9
1.4.2 INSTALLATION NOTES	9
2 SPECIFICATIONS	10
2.1 PROCESSOR	10
2.2 MEMORY	10
2.3 DC SUPPLY	10
2.3.1 FUSING	10
2.3.2 IGNITION (PIN A13)	11
2.4 ENVIRONMENTAL	11
2.5 USER INTERFACE	11
2.5.1 CONTROLS	11
2.5.2 DISPLAY	11
2.5.3 LED	12
2.6 REAL TIME CLOCK	12
2.7 INPUTS	13
2.7.1 DIGITAL INPUTS	13
2.7.1.1 DIGITAL	13
2.7.1.2 FREQUENCY	13
2.7.2 ANALOGUE INPUTS	13
2.7.2.1 VOLTAGE	13
2.7.2.2 CURRENT	14
2.7.2.3 RESISTIVE	14
2.7.2.4 RATIOMETRIC	14
2.8 OUTPUTS	15
2.8.1 NEGATIVE SWITCHING	15
2.8.2 POSITIVE SWITCHING	15
2.8.3 P.W.M.	15
2.8.4 VREF	15
2.9 COMMUNICATIONS	16
2.9.1 CAN	16
2.9.2 ETHERNET	16
2.9.3 USB	16
2.10 CAMERA INPUTS	17
2.11 APPLICABLE STANDARDS	17
3 INSTALLATION	18
3.1 DIMENSIONS AND MOUNTING	18
3.1.1 DIMENSIONS	18
3.1.2 FASCIA MOUNTING	19
3.1.3 RAM MOUNTING	20
3.2 FUSING	21
3.3 TYPICAL CONNECTION DIAGRAM	21
3.4 USER CONNECTIONS	22
3.4.1 CONNECTOR A	23
4 OPERATION	25
4.1 SYSTEM PAGES	25
4.1.1 NAVIGATION	25
4.1.1.1 PAGE SELECTION	25
4.1.1.2 OPTION SELECTION AND EDITING	25

4.1.2	DEVICE SETTINGS	26
4.1.2.1	NETWORK	26
4.1.2.2	CAN	27
4.1.2.3	BACKLIGHT	27
4.1.2.4	REAL TIME CLOCK	27
4.1.3	DEVICE ACTIONS	28
4.1.3.1	INSTALL SPLASH SCREEN	28
4.1.3.2	CLONE / RECOVER SELECTION	29
4.1.3.3	FORMAT MEMORY / DATA	30
4.1.3.4	KEYTEST	30
4.1.3.5	'HISTORY	31
4.1.4	DEVICE INFORMATION	31
4.2	FIRMWARE UPDATE AND FILE SYSTEM OPERATIONS	32
5	CONNECTING TO CODESYS.....	33
5.1	START NEW PROJECT	33
5.2	CONNECT BY AUTOMATIC SCAN	34
5.3	CONNECT BY IP ADDRESS	36
5.4	CONFIGURE SETTINGS AND MONITOR THE DEVICE	37
5.4.1	DEVICE SETTINGS PARAMETERS	38
5.4.2	MANUAL SHUTDOWN	39
5.4.3	DEVICE SETTINGS I/O MAPPING	39
5.5	ADD INPUTS, OUTPUTS AND BUTTONS TO THE PROJECT	40
5.5.1	BUTTONS	41
5.5.1.1	BUTTON LOCATION	41
5.5.1.2	BUTTON SETTINGS	42
5.5.2	INPUTS AND OUTPUTS	43
5.5.3	DIGITAL INPUT PARAMETER CONFIGURATION	44
5.6	USING THE DISPLAY IN THE PROJECT	44
5.6.1	INSTALLING FONTS TO DSEM840	46
5.6.2	USING CUSTOM IMAGES	47
5.6.2.1	ADDING AN IMAGE POOL	47
5.6.2.2	ADDING IMAGES TO THE IMAGE POOL	47
5.6.2.3	USING THE IMAGE POOL ON THE DISPLAY	48
5.6.2.4	IMAGE TRANSPARENCY	49
5.7	USING PERSISTENT VARIABLES IN THE PROJECT	50
5.8	APPLICATION UPDATE	51
5.8.1	CREATION OF THE BOOT APPLICATION AND .PKG FILE	51
5.8.2	APPLICATION UPDATE USING USB	52
5.9	PROGRAMATIC FILE ACCESS	53
5.9.1	BROWSING THE FILE SYSTEM USING CODESYS	53
5.10.2	UPDATE USING DSESERVICE TOOL AND ETHERNET CONNECTION	55
5.11	USING NETWORK VARIABLES IN THE PROJECT	56
5.12	USING CAN IN THE PROJECT	57
5.12.1	DSE_CAN	57
5.12.2	CODESYS J1939	58
5.13	UNSUPPORTED CODESYS VISUALISATION ITEMS	61
6	DSEM840 CODESYS ERROR CODES	62
6.1	DEVICE	62
6.2	ANALOGUE INPUTS	62
6.3	DIGITAL INPUTS	63
6.4	DIGITAL OUTPUTS	63
7	FIRMWARE UPDATE	64
8	CABLES, CONNECTORS, HARNESSSES AND SPARE PARTS	65
8.1	DSEM840 CONNECTOR HARNESS KIT (016-168)	65
9	TROUBLESHOOTING	66
10	MAINTENANCE AND WARRANTY	67

11	DISPOSAL	67
11.1	WEEE (WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT)	67

1 INTRODUCTION

This document details the operation and setup requirements of the DSEM840 Mobile Controller and Display, part of the DSEControl® range of products.

The manual forms part of the product and should be kept for the entire life of the product. If the product is passed or supplied to another party, ensure that this document is passed to them for reference purposes.

This is not a *controlled document*. DSE do not automatically inform on updates. Any future updates of this document are included on the DSE website at www.deepseapl.com

Observe the operating instructions. Non-observance of the instructions, operation not in accordance with use as prescribed below, wrong installation or incorrect handling seriously affects the safety of operators and machinery.

A robust metal case designed for chassis mounting houses the module. Connections are via locking plug and sockets.




The controller is supplied with no application program. The equipment manufacturer is responsible for creating and managing the application program and installing it in the controller. This is achieved using CODESYS V3.5 or C programming. Contact DSE Technical Support for further details.

DSEM840-02 offers increased performance over the original DSEM840-01 while maintaining identical mechanical and connection details. Differences are detailed in the section entitled *Specifications* elsewhere in this document.



1.1 CLARIFICATION OF NOTATION

Clarification of notation used within this publication.

 NOTE:	Highlights an essential element of a procedure to ensure correctness.
 CAUTION!	Indicates a procedure or practice, which, if not strictly observed, could result in damage or destruction of equipment.
 WARNING!	Indicates a procedure or practice, which could result in injury to personnel or loss of life if not followed correctly.

1.2 GLOSSARY OF TERMS

Term	Description
Application	The application is the program that allows the DSEM840 to control the machine it is connected to. The Application within the DSEM840 is designed and provided by the manufacturer of the complete machine.
Bootloader	The Bootloader is the program within the DSEM840 responsible for loading the Operating System.
CAN	Control Area Network. A high-speed data transmission system used extensively within the Automotive and Off-Highway industries.
CODESYS	Integrated Development Environment for programming controller applications according to the international industrial standard IEC 61131-3. DSEM840 supports CODESYS V3.5
DSEServiceTool	DSE Software used to load packages to the DSE M Series devices.
ECU	Electronic Control Unit. For example, the DSEM840 device.
Firmware	The Firmware of the DSEM840 is the Operating System of the DSEM840 that reads and executes the Application program.
FSD	Full Scale Deflection. For example, 0 mA to 20 mA is the Full Scale Deflection of a current sink input.
I/O	Input / Output. For example, "The I/O is taken out to an external terminal strip in the user panel".
IDE	Integrated Development Environment. For example, the CODESYS V3.5 application that runs on the host PC is an IDE.
Ixyy	An Input, where x is the connector and yy is the input number. For example IA003 means Input 3 on Connector A.
M840-01	(Full part number M840-xxx-01). Original version of the device.
M840-02	(Full part number M840-xxx-02). Enhanced version of the device released 2021 offering increased processing power, memory, and functionality while retaining the pinout and mechanical dimensions of the original M840-01.
PLC	Programmable Logic Controller. Industrial computer used primarily for the automation of electromechanical machinery.
PWM PWMi	A digital signal is used to represent an analogue value by using Pulse Width Modulation. The mark-space ratio of a square wave changes to represent the value. Used for many control applications including proportional valves. PWM= Voltage control.

Off-Highway	An industrial vehicle used primarily “off road”. For example construction and farm machinery. A wider interpretation includes on road access platforms, emergency vehicles and other industrial machinery, used either on the road, or off road.
Pin	A male or female pin connection in a housing (plug or socket).
Qxyyy	An Output, where x is the connector and yyy is the output number. For example QA002 means Output 2 on Connector A.

1.3 RELATED INFORMATION

This document refers to, and is referred by the following DSE publications which are obtained from the DSE website: www.deepseapl.com or by contacting DSE technical support: support@deepseapl.com.

1.3.1 TECHNICAL INFORMATION

DSE Part	Description
055-222	DSEM840 Datasheet
053-188	DSEM840 Installation Instructions
057-265	DSEServiceTool Software Manual

1.4 SAFETY INSTRUCTIONS

1.4.1 GENERAL

- These instructions are for authorised persons according to the EMC and low-voltage directives. The device must be installed, connected and put into operation by a qualified electrician.
- It is not permissible to open the controller or to modify or repair the controller. Modification or repairs to the wiring could result in dangerous malfunctions. Repairs to the controller must be performed by DSE. Contact your original equipment supplier in the case of malfunction.
- When the device is unpowered, ensure that no connection pins are connected to a voltage source. Thus, when the supply is switched off, the supply for the electronics, the power outputs and the external sensor supply must be switched off together.
- Do not insert or remove the connector when powered. Remove all sources of supply before insertion or removal.
- The customer is responsible for performing risk analysis of the mobile working machine and determining the possible safety related functions. The user is responsible for the safe function of the application programs created. If necessary, they must additionally carry out an approval test by corresponding supervisory and test organisations according to the national regulations.
- All connectors must be unplugged from the electronics during electrical welding and painting operations.

1.4.2 INSTALLATION NOTES

- Follow the instructions of the connector manufacturer, specifically with respect to preventing water from entering the device. See Section entitled *Cables, Connectors, Harnesses and Spare Parts* for details of DSE Part Numbers.
- To maintain IP67 rating where a connector is completely unused, ensure the use of a suitable blanking insert as recommended by the connector manufacturer.
- To maintain IP67 rating where connectors have unused pins, ensure the use of a suitable blanking insert as recommended by the connector manufacturer.
- M12 protection plugs (supplied) must be installed in both the USB and Ethernet interfaces to ensure IP67 rating when the connectors are not in use. Where IP protection is required when the interfaces are in use, suitable O-rings must be fitted. Silicon Grease to protect the O-rings is recommended.

2 SPECIFICATIONS

Specification tables below cover both DSEM840-02 and the original DSEM840-01. Where not listed, the specification covers both device versions.

2.1 PROCESSOR

Description	DSEM840-01	DSEM840-02
Processor Type	NXP LPC4357 dual core M4 & M0	STM32H745 dual core M7 & M4
Speed	200 MHz	M7 @ 400 MHz M4 @ 200 MHz

2.2 MEMORY

Description	DSEM840-01	DSEM840-02
Flash	16 MB Total	32 MB Total 20 MB Available to CODESYS
RAM	32 MB Total	64 MB Total 48 MB Available to CODESYS
Retained Data	N/A	8 kB, Data Written to Non-Volatile memory at 1 Hz rate
System Event Log	N/A	2 MB Configurable on/off

2.3 DC SUPPLY

Description	Specification
Operating Voltage (Pin A7)	8 V to 32 V Operation to 5 V for 500 ms providing supply was 5 V previously. Protection to 55 V for 200 ms
Maximum Current (Full Backlight, no External Loads)	<1000 mA at 24 V
Maximum Current (Full Backlight & Heater, no External Loads)	<1500 mA at 24 V
Maximum Current (After Controlled Shutdown With Ignition off)	<0.1 mA at 24 V

2.3.1 FUSING

Description	Specification
DC Supply (Pin A7) Supplies DSEM840 and High Current Outputs Fuse as Required by Output Loads (Pins A2, A3, A4, A5)	3 A Min (to supply DSEM840) 10 A Max
Ignition (15) (Pin A13)	1 A Max

2.3.2 IGNITION (PIN A13)

NOTE: M840-01 only: Ignition (Pin A13) must be utilised correctly to enable / disable the application program. This ensures that *Persistent Variables* (e.g., logs and other changed parameters) and other files are saved correctly. Incorrect device shutdown while using the file system may result in loss of Application Program.

NOTE: Should it be required to perform a programmatic shutdown sometime after removal of *Ignition*, see section entitled *Manual Shutdown* elsewhere in this document.

Pin A7 is used to give a constant DC supply to the DSEM840, with the Ignition pin being used to energise and de-energise the ECU. Typically, this pin is controlled by an external ignition switch. To stop the application, de-energise the Ignition pin. This allows the DSEM840-01 to store any changed parameters and logs before closing. For M840-02, persistent vars are saved automatically, at regular intervals.

Description	Specification
Ignition Pin Active	>5 V

2.4 ENVIRONMENTAL

Description	DSEM840-01	DSEM840-02
Operating Temperature	-30 °C to +65 °C (-22 °F to 149 °F)	-30 °C to +70 °C (-22 °F to 158 °F)
Storage Temperature	-40 °C to +80 °C (-40 °F to 176 °F)	-40 °C to +80 °C (-40 °F to 176 °F)
Degrees of Protection Provided by Enclosure (With All Mating Connectors Fitted)	IP67 (NEMA 6)	IP67 (NEMA 6)

2.5 USER INTERFACE

2.5.1 CONTROLS

Description	Specification
Push Buttons	14

2.5.2 DISPLAY

Description	Specification
Size (Across Diagonal)	109 mm (4.3")
Size (W x H)	WQVGA (480 x 272)
Aspect Ratio	16:9
Type	Optically Bonded TFT
Lifetime	> 30,000 hours
Colour	24 bit
Splash Screen Image Type	Uncompressed Bitmap Image (BMP) 24 bit Colour 480 x 272 Spaces are not permitted within the image filename.


2.5.3 LED

The system LED is used to indicate operating status.

Description	Specification
LED Type	Tricolour (Red, Amber, Green) (see below)

Colour	Operation	State	Meaning
Off	N/A	Off	Device not powered
Green	Static	Application Stopped.	Unit powered up, Application program loaded but not running
	1Hz flash	Application Running.	Unit powered up, Application program loaded and running
	5Hz flash	No Application.	Unit powered up, but no Application program loaded
Amber	Static	Bootloader Mode	Bootloader functioning normally, firmware present
		Firmware Start-up	Firmware is at Start-up.
		Application Exception	Unit Stopped due a serious fault.
	1Hz flash	Decrypting Image	Bootloader is decrypting the downloaded image
	5Hz flash	Reading Image from USB	Bootloader is reading an image from the USB
Red	Static	Fatal Error	Fatal system / hardware fault – LED may be driven directly by microcontroller error pin or firmware is in fault condition state.
	1Hz flash	Faulty Application Running	Unit running with a serious fault, see CODESYS error flags or Web Tool

2.6 REAL TIME CLOCK

 **NOTE:** The *Real Time Clock* is adjustable within the *Settings Pages*. For further details see section entitled *Operation | Device Settings | Real Time Clock* elsewhere in this document.

Description	Specification
Retention Type	Standard RTC.
Retention Time (Approx.)	5 years

2.7 INPUTS

2.7.1 DIGITAL INPUTS

2.7.1.1 DIGITAL

Description	Specification
Applicable Pins	Pins A10, A11, A16, A17
Minimum Voltage For High Level	Configurable
Maximum Voltage For Low Level	Configurable
Active Mode	Configurable
Whetting Current	Min 1.6 mA

2.7.1.2 FREQUENCY

Description	Specification
Applicable Pins	Pins A10, A11, A16, A17
Frequency Range	5 Hz to 30 kHz
Resolution	100 Hz at Maximum Frequency
Accuracy	400 Hz at Maximum Frequency
Minimum Voltage For High Level (Mark)	DSEM840-01: >4 V DSEM840-02: >2.4 V
Maximum Voltage For Low Level (Space)	DSEM840-01: <0.5 V DSM840-02: <0.9 V

2.7.2 ANALOGUE INPUTS

Description	Specification
Applicable Pins	Pins A10, A11, A16, A17
Reference Voltage Pins	A6
Reference Voltage	Programmable 0 V / 5 V / 10 V ±500 mV

2.7.2.1 VOLTAGE

Description	Specification
Applicable Pins	Pins A10, A11, A16, A17
Configurable Ranges	0 V to 5 V 0 V to 10 V 0 V to 32 V
Input Resistance	≥7.5 kΩ
Sampling Rate	500 Hz
Resolution	DSEM840-01: 10 bits DSEM840-02: 12 bits
Accuracy	± 1 % FSD

Specifications

2.7.2.2 CURRENT

Description	Specification
Applicable Pins	Pins A10, A11, A16, A17
Configurable Ranges	0 mA to 20 mA 4 mA to 20 mA
Input Type	Current sink only
Input Sink Resistance	DSEM840-01: 100 Ω \pm 1% DSEM840-02: 150 Ω \pm 1%
Sampling Rate	500 Hz
Resolution	DSEM840-01: 10 bits DSEM840-02: 12 bits
Accuracy	\pm 1 % FSD

2.7.2.3 RESISTIVE

Description	Specification
Applicable Pins	Pins A10, A11, A16, A17
Measurement Range	0 Ω to 3400 Ω
Measurement Source Current	1 mA
Sampling Rate	500 Hz
Resolution	DSEM840-01: 10 bits DSEM840-02: 12 bits
Accuracy (\pm 1 % Full Scale Deflection)	\pm 1 % FSD

2.7.2.4 RATIOMETRIC

Description	Specification
Applicable Pins	Pins A10, A11, A16, A17
Measurement Voltage Reference	Configurable (Supply / VREF)
Measurement Type	Ratio of input Pin to Reference
Resolution	DSEM840-01: 10 bits DSEM840-02: 12 bits
Accuracy	\pm 1 % FSD

2.8 OUTPUTS

2.8.1 NEGATIVE SWITCHING

Description	Specification
Applicable Pins	Pins A2, A3, A4, A5
Maximum Current	1 A
Digital Output Active Low 'ON' State Maximum Voltage at Rated Current	< 500 mV
Low Side Digital Output Active Low 'OFF' State Leakage Current	<2 mA

2.8.2 POSITIVE SWITCHING

Description	Specification
Applicable Pins	Pins A2, A3, A4, A5
Maximum Current	1 A
Digital Output Active High 'ON' State Maximum Voltage Drop at Rated Current	<1500 mV
High Side Digital Output Active High 'OFF' State Leakage Current	<10 μ A at 24 V output supply

2.8.3 P.W.M.

 **NOTE: P.W.M. Outputs available only on DSEM840-02 V4.1 onwards.**

Description	Specification
Applicable Pins	Pins A2, A3,
Maximum Current	1 A
P.W.M. Active High 'ON' State Maximum Voltage Drop at Rated Current	<1500 mV
P.W.M. Active High 'OFF' State Leakage Current	<10 μ A at 24 V output supply
P.W.M. Frequency	0 Hz to 250 Hz
P.W.M. Duty Cycle Range	0 % to 100 % (Subject to Minimum Pulse Width)
P.W.M. Duty Cycle Resolution	0.1 %
P.W.M. Minimum Mark (On Pulse) Width	200 μ s
P.W.M. Minimum Space (Off Pulse) Width	200 μ s

2.8.4 VREF

Configurable output voltage suitable for supply external circuits such as input sensors.

Description	Specification
Applicable Pins	Pin A6
Voltage	Configurable (Disabled, 5 V, 10 V)
Accuracy Under Load	1 %
Maximum Source Current	100 mA
OFF State Leakage Current	< 100 μ A

2.9 COMMUNICATIONS

2.9.1 CAN


NOTE: CAN connections are NOT internally terminated. A complete CAN network must have 120 Ω terminators at each end of the network.

NOTE: Screened 120 Ω impedance cable specified for use with CAN must be used for the CAN links.
DSE stock and supply Belden cable 9841 which is a high quality 120 Ω impedance cable suitable for CAN use (DSE part number 016-030).

Description	Specification
Number of CAN Interfaces	2
Supported Protocols	J1939 (as Type I ECU (no internal termination resistor)) CAN open Raw CAN
Supported Baud Rates	50 kbit/s, 100 kbit/s, 125 kbit/s, 250 kbit/s, 500 kbit/s, 800 kbit/s, 1 Mbit/s


2.9.2 ETHERNET

Description	Specification
Number Of Ethernet Ports	1
Supported Data Rates	10 Mbit/s / 100 Mbit/s, Duplex
Supported Protocols	MODBUS TCP CODESYS 3.5

M12 'D' Coded – 4 Pin Female	Pin	Description
	1	Tx+
	2	Rc+
	3	Tx-
	4	Rc-

2.9.3 USB

Description	Specification
Number of USB Ports	1
USB Version	2
Supported Speeds	Full Speed (12 Mbit/s)
Device Class	08 (Mass Storage)
Max Size	64 GB
Filing System	VFAT or FAT32

M12 'B' Coded – 5 Pin Female	Pin	Description
	1	5 V
	2	Data-
	3	Data+
	4	0 V
	5	Shield

2.10 CAMERA INPUTS

Description	Specification
Number of Camera Inputs	1
Connection Pins	A12 (signal), A18 (gnd).
Interface Type	Analogue (Composite) Video for PAL / NTSC

2.11 APPLICABLE STANDARDS


Category	Description	Standard
CE marking	Electromagnetic compatibility (EMC) noise immunity	BS EN 61000-6-4:2007 +A1:2011
	Electromagnetic compatibility (EMC) emission standard	BS EN 61000-6-2:2005
	Safety requirements for electrical equipment for measurement, control, and laboratory use	BS EN 61010-1:2010 BS EN 61010-2-030:2010
E11 (Not Applicable to DSEM840-01)	EMC requirements for vehicles Radiated R.F. immunity 30 V/m	UN/ECE-R10.05 ISO 11452-2
Climatic tests	Cold testing – Low temperature storage	BS EN 60068-2-1
	Dry heat – Max temperature storage	BS EN 60068-2-2
	Dry heat – Max operating temperature	BS EN 60068-2-2
	Damp heat testing – High humidity surface condensation	BS EN 60068-2-30
	Composite temperature/humidity cyclic test	BS EN 60068-2-38
Vibrations tests	Damp heat, steady state	BS EN 60068-2-78
	Resonance Search	BS EN 60068-2-6
	Vibration, random mounting location: vehicle body	ISO 16750-3: 2012 Test VII
	Test Fh: Vibration, broadband random and guidance	IEC 60068-2-64
Electrical (Not Applicable to DSEM840-01)	Shock resistance	BS EN 60068-2-27
	Road vehicles – Mechanical loads - Shocks	ISO 16750-3
	Road vehicles – Electrical loads	ISO 16750-2
	Conducted Transient Emissions	ISO 7637-2:2004
	Conducted Transient Immunity	ISO 7637-2:2004

3 INSTALLATION

3.1 DIMENSIONS AND MOUNTING


3.1.1 DIMENSIONS

Description	Specification
Overall Dimensions (Height x Width x Depth)	208 mm x 131 mm x 56 mm (8.18 " x 5.14 " x 2.19 ")
Mounting Type	4 x mounting bolts or RAM mount.
Overall Weight	<1 kg (2.2 lb)



3.1.2 FASCIA MOUNTING


Description	Specification
Fascia Mounting Holes	Suitable for M5 bolts (0.3 " holes)
Fascia Mounting Hole Centres	180 mm x 70 mm (7.09 " x 2.76 " See Diagram Below
Panel Cut-Out	163 mm x 98 mm (6.42 " x 3.86 ")
Fascia Mounting Bolt Material Recommendation	Steel or Stainless Steel bolts fitted with M5 bonded seal washers (also known as Dowty washers).
Fascia Mounting Bolt Tightening Torque to prevent distortion of the sealing gasket and subsequent seal failure / mechanical damage to the controller.	1.2 Nm Maximum (0.89 ft. lb Maximum)



3.1.3 RAM MOUNTING

DSEM840 has four holes on the rear face, suitable for fitting of a RAM type mount. The spacing for the mounting holes is detailed in the image below.

Description	Specification
RAM Mounting Holes	Suitable for M5 bolts (0.3 " holes)
RAM Mounting Hole Centres	30 mm x 38 mm (1.19 " x 1.50 ")
RAM Mounting Bolt Material Recommendation	Steel or Stainless Steel
RAM Mounting Bolt Tightening Torque	4 Nm Maximum (2.95 ft. lb Maximum)






3.2 FUSING

The individual electric circuits must be protected in order to protect the whole system. Select appropriate fuses to protect the outputs being supplied.

Pin	Description	Comments	Recommended Fuse Size
A7	ECU Supply	Supplies DSEM840 CPU and Outputs	3 A to 10 A Max
A13	Ignition (15)		1 A Max


3.3 TYPICAL CONNECTION DIAGRAM



3.4 USER CONNECTIONS

▲ NOTE: If a prewired connection cable is used, remove the cores with unused signal inputs and outputs. Unused cores, in particular core loops, lead to interference coupling that can influence the connected controller.

▲ NOTE: USB and Ethernet connectors are coded differently. Do not try to force a connector into the wrong socket.



3.4.1 CONNECTOR A

NOTE: For details of fuse requirements, refer to section entitled *Fusing* elsewhere in this document.


NOTE: Ignition (Pin A13) must be utilised correctly to enable / disable the application program. This ensures that logs and other changed parameters are stored when the Ignition is switched off.

NOTE: Screened 120 Ω impedance cable specified for use with CAN must be used for the CAN links.
DSE stock and supply Belden cable 9841 which is a high quality 120 Ω impedance cable suitable for CAN use (DSE part number 016-030).

NOTE: CAN connections are NOT internally terminated. A complete CAN network must have 120 Ω terminators at each end of the network.

NOTE: Connect Camera using a single core conductor with screen (shield).

Terminology	Meaning
QA00x	Output
IA00x	Input
H	Output, High when active.
L	Output, Low when active.
PWM	Output has PWM capability.
AIN, FREQ	Input configurable to accept signals as positive digital, negative digital, 0 V to 5 V, 0 V to 10 V, 0 V to 32 V, 0 mA to 20 mA, 4 mA to 20 mA, ratiometric or resistive and frequency measuring

Connector A	Pin	Description	Comments
<p>(A Coded)</p> 	1	ECU Supply -ve	DC Supply negative for the DSEM840
	2	QA002	OUT H, L, PWM
	3	QA001	OUT H, L, PWM
	4	QA004	OUT H, L
	5	QA003	OUT H, L
	6	VREF +	VREF output for AIN
	7	ECU Supply +ve	DC Supply positive for the DSEM840
	8	CAN1 H	
	9	CAN2 H	
	10	IA001	AIN, FREQ
	11	IA002	AIN, FREQ
	12	Camera Signal	Analogue (Composite) video
	13	Ignition +ve (15)	Energises the ECU.
	14	CAN1 L	
	15	CAN2 L	
	16	IA003	AIN, FREQ
	17	IA004	AIN, FREQ
	18	Camera GND	Screen/GND for Camera

4 OPERATION

4.1 SYSTEM PAGES

The System Information and System Settings pages are accessed by pressing and holding any two of the fascia buttons during the power up (application of Ignition input with DC power supplied) of the DSEM840. Wait until *Entering Setup...* is displayed before releasing the buttons.

4.1.1 NAVIGATION

Within the System Pages, the following icons appear adjacent to the buttons to indicate their function.

Icon	Function	Description
ESC	Return	Return to a previous page.
◀▶▲▼	Navigate	Navigate through the available selections.
OK	OK / Accept	Accept/Edit the current selection, Save the value being edited.

4.1.1.1 PAGE SELECTION

Use the ◀ / ▶ buttons to move through the pages. Press **OK** to select the page. Press **ESC** to exit the editor and return to the main application.



4.1.1.2 OPTION SELECTION AND EDITING


While viewing the selected page, use the ◀ / ▶ buttons to move through the options, Press **OK** to select the option for editing.

While editing the selected parameter, use the ▲ / ▼ buttons to change the value, Press **OK** to save the change.

Press **ESC** to exit the editor.

4.1.2 DEVICE SETTINGS

This section allows access to the *Device Settings*.



4.1.2.1 NETWORK



This section allows selection of DHCP or Static IP address. When connecting the device to a third party network, these settings must be made after consultation with the network manager.

Press **OK** to enable / disable *DHCP Option*.

Selecting *DHCP Option* instructs the device to obtain the network settings automatically from a DHCP server on the connected network. When unselected, the network options are user configured.

Press the **▲** / **▼** buttons to move through the options, Press **OK** to select the option for editing. Press **ESC** to exit the editor.

While editing the parameter, use **◀** / **▶** buttons to move through the digits, use **▲** / **▼** buttons to change the value of the selected digit. Press **OK** to save the change. Press **ESC** to exit the editor.




4.1.2.2 CAN

This section allows configuration of the CAN interface parameters.

Press the ▲ / ▼ buttons to move through the options, Press **OK** to select the option for editing.

Selecting *Interface* and pressing **OK** cycles between the two CAN ports (0 & 1).




4.1.2.3 BACKLIGHT

NOTE: Manual setting may be overridden by the application if it has been programmed to adjust the backlight level. This is application dependent.

This section allows adjustment of the LCD backlight brightness.


Use the ◀ / ▶ buttons to change the brightness, Press **OK** to save the change. Press **ESC** to exit the editor.



4.1.2.4 REAL TIME CLOCK


Allows the setting of the Real Time Clock and Calendar.

While editing the parameter, use the ◀ / ▶ buttons to change between fields and ▲ / ▼ buttons to change the highlighted value. Press **OK** to save the change. Press **ESC** to exit the section.



4.1.3 DEVICE ACTIONS

Allows selection of device actions.




4.1.3.1 INSTALL SPLASH SCREEN

DSEM840 supports the display of a *Splash Screen* at power up of the device. This is typically used to display the OEM logo image.

The device Password is required (when enabled) to allow Splash Screen installation.

Supported Splash Screen Image Type:
 Uncompressed Bitmap Image (BMP)
 24-bit Colour
 480 x 272
 Spaces are not permitted within the image filename.




Press **ESC** to exit the section.

Press the ▲ / ▼ buttons to select the required file, Press **OK** to apply it

4.1.3.2 CLONE / RECOVER SELECTION

The device Password is required (when enabled) to allow Clone or Recover operations.

Press the ▲ / ▼ buttons to select the required function, Press **OK** to access it. Press **ESC** to exit the section.



CLONE

NOTE: Before cloning the device, consider if any files remain on the device from other (previous) applications. For this reason, it is recommended to *Format* the device to remove all files from the previous application, then redeploy the application to be *Cloned*. For details see section entitled *Operation / System Pages / Device Actions / Format Memory / Data*.


NOTE: Max 8 GB USB Memory Device is supported for *Clone* function.

This section is used to create a backup file of the device, selecting the elements to backup.

This file may then be used to recover the device, or create *Clones*, sending the file to other devices.

Press the ▲ / ▼ buttons to select the required section to Clone, Press **OK** to action it.

Ensure the USB device (FAT / FAT32 formatted, Max 8 GB) used to store the Clone file(s) is connected to the controller. Press **ESC** to exit the section.



RECOVER

NOTE: The *Recover* process replaces files on the target device and may change the Application of the device.

This section is used to recover the device from a previously stored Clone (backup) file.

Ensure the USB device containing the file(s) to Recover is connected to the controller. All applicable files are listed.

Press the ▲ / ▼ buttons to select the required file, Press **OK** to apply it. Press **ESC** to exit the section.



4.1.3.3 FORMAT MEMORY / DATA


NOTE: The *Format* process deletes files on the target device and may change the operation of the device.

Select which memory area to Format.

Press the ▲ / ▼ buttons to select the required function, Press **OK** to access it. Press **ESC** to exit the section.

Format Memory: Application and files are removed.

Format App/Factory Settings: Application and files are removed. Memory is cleared including persistent variables. Restored to Factory Settings.




4.1.3.4 KEYTEST

This section allows the device fascia buttons to be tested.


Press the keys to receive feedback of their operation.

To exit the Keytest, release all buttons for five seconds.



4.1.3.5 'HISTORY

Used to display a log of the date of certain actions.
Press **ESC** to exit the section.



4.1.4 DEVICE INFORMATION

This section shows the *Device Information*.




4.2 FIRMWARE UPDATE AND FILE SYSTEM OPERATIONS

NOTE: *Load from USB* process deletes files on the target device and may change the operation of the device.

This section allows new files and firmware to be installed.

- Remove Ignition from the DSE840.
- Press and hold any three buttons.
Reapply Ignition until the *Boot Menu* is displayed. Now release the buttons to enter the Boot Menu.

Press ◀ / ▶ / ▲ / ▼ buttons to select the required option.
Press **OK** to access the selected function.
Press **ESC** to exit the section.




5 CONNECTING TO CODESYS

NOTE: Before deploying a new application to the device, it is recommended to *Format* the device to remove all files from the previous application. For details see section entitled *Operation | System Pages | Device Actions | Format Memory | Data*.


DSEM840 communicates with, and is programmed by, the CODESYS V3.5 Integrated Development Environment (IDE) version 3.5.12.0.

5.1 START NEW PROJECT

To begin, start a new project as shown.



If you didn't select a template from the previous dialogue, now select the model type




5.2 CONNECT BY AUTOMATIC SCAN

NOTE: A device in *System Settings* or *Bootloader* mode cannot be found in the *Scan* and cannot connect to CODESYS.



NOTE: The *Scan* requires the device to be on the same subnet as the PC. If this is not possible, locate the IP address of the device and connect a detailed in the section entitled *Ethernet TCP* elsewhere in this document.

NOTE: If the IP address of the device is known, connection may also be achieved manually as detailed in the section entitled *Ethernet TCP* elsewhere in this document.


This method of connection is suitable only for devices in the same subnet as the PC. With the device connected to the same Ethernet network as the PC, Select *Device | Communication Settings* in the CODESYS V3.5 IDE.



Connecting to CODESYS



Click OK to connect to the selected device.



5.3 CONNECT BY IP ADDRESS

NOTE: A device in *System Settings* or *Bootloader* mode cannot connect to CODESYS.

NOTE: If the IP address of the device is not known, see the section entitled *Connect by Automatic Scan* elsewhere in this document.

This method of connection is particularly suited for devices on other subnets or networks, providing the PC has a routable connection to the device.

Select *Device | Communication Settings* in the CODESYS V3.5 IDE.


Double-Click *Device*...

...then click *Communication Settings*

Where the IP address of the device is known, this is entered directly into the address bar. Press *Enter* to make the connection.

Successful connection is shown by the green icon.

5.4 CONFIGURE SETTINGS AND MONITOR THE DEVICE



See the following subsections for details of the Device Settings pages.

5.4.1 DEVICE SETTINGS PARAMETERS

...and then select *Device Settings Parameters...*

Parameter	Type	Value	Default Value	Unit	Description
New Ethernet Configuration					
Voltage Reference	Enumeration of USINT	Disabled	Disabled		
Battery Voltage	Enumeration of USINT	12V	12V		
Manual Shutdown	BOOL	TRUE		0	Overrides automatic SHUTDOWN on ignition power loss

Enables the VREF auxiliary voltage output.

Enables *Manual Shutdown*.

SAVE CONFIG

Parameter	Type	Value
New Ethernet Configuration		
Save Config	Enumeration of USINT	No
IP Mode	Enumeration of UINT	No
WebConfig Port	UDINT	Yes
IP Address		

When set to **YES**, the network settings configured below are set when the device powers up. This overwrites any other setting that has been made, either programmatically or within the *System Settings* of the device.

5.4.2 MANUAL SHUTDOWN

NOTE: Enable *Manual Shutdown* in *Device Settings*.

NOTE: Calling *DSE.SystemShutdown* when *Ignition* pin remains active, results in DSEM840 shutting down and restarting (ie similar to a power cycle).

Manual Shutdown parameter is controlled by either mapping a BOOL variable within *Device Settings I/O Mapping*:

Application.PLC_PRG.bIgnitionSwitch	Ignition Switch	%IX126-0	BIT	Ignition Switch
-------------------------------------	-----------------	----------	-----	-----------------

or by utilising the function:

```
DSE.SystemSetManualShutdown(TRUE); or DSE.SystemSetManualShutdown(FALSE);
```

When *Manual Shutdown* is set to *TRUE*, removal of the *Ignition* pin does not begin the shutdown process. Instead, the application can monitor the *Ignition* pin, performing a graceful machine shutdown, before programmatically instructing DSEM840 to shutdown using the function:

```
DSE.SystemShutdown();
```

Ignition pin may be monitored either by mapping *Ignition Switch* within the *Device Settings I/O Mapping* page, or by using:


```
DSE.SystemGetIgnition(Ignition => bIgnitionState);
```

Where *bIgnitionState* is a BOOL variable used to store the state of the system *Ignition* pin.

To restart the M840 application, reapply *Ignition* pin.



5.4.3 DEVICE SETTINGS I/O MAPPING

This page is used to monitor the device, and if required, to map the monitored values to program variables.



Error Code is a bit field, detailed in the section entitled *DSEM840 CODESYS Error Codes* elsewhere in this document.

5.5 ADD INPUTS, OUTPUTS AND BUTTONS TO THE PROJECT





5.5.1 BUTTONS

5.5.1.1 BUTTON LOCATION


The below image shows the location of the buttons along with their default names within the CODESYS environment.



5.5.1.2 BUTTON SETTINGS





Parameter	Description
Hold Threshold	Amount of time (in milliseconds) that the button must be pressed before it is considered 'held down'.




Parameter	Description
State	Indicates if the button is pressed (1) or not pressed (0).
Held	Indicates if the button has been held for longer than the duration of the <i>Hold Threshold</i> (1) or not (0).
Hold Time	The amount of time (in milliseconds) that the button has been pressed for (zero if not currently pressed).

5.5.2 INPUTS AND OUTPUTS



5.5.3 DIGITAL INPUT PARAMETER CONFIGURATION





Parameter	Description
Active Mode	Active High: The input connects to the positive supply rail when activated. Active Low: The input connects to the negative supply rail when activated.
Resistor	Float: The input is floating when no connection is made. Used where the external sensor (NPN Sinking or PNP Sourcing type) has an integrated pull-up or pull down resistor. Pull Up: An internal pull up resistor biases the input to the positive supply rail when no connection is made. Commonly used with NPN (Sinking) type switched sensors and volt-free contacts. Pull Down: An internal pull down resistor biases the input to the negative supply rail when no connection is made. Commonly used with PNP (Sourcing) type switched sensors and volt-free contacts.
Higher Threshold	For <i>Active High</i> inputs, the input is detected as being active when above this threshold with respect to the negative supply rail.
Lower Threshold	For <i>Active Low</i> inputs, the input is detected as being active when below this threshold with respect to the negative supply rail.

5.6 USING THE DISPLAY IN THE PROJECT

NOTE: Ensure Visualisation elements do not fall outside the boundary of the visible screen area.

CODESYS 3.5 includes the facility to design and manipulate the LCD of the device. While the operation of the CODESYS environment is detailed within the CODESYS online document, this section provides a quick-start guide to using the *Visualisation* component of CODESYS 3.5.



Connecting to CODESYS





5.6.1 INSTALLING FONTS TO DSEM840

NOTE: If the *Font Settings* tab is not visible within the Visualization Manager, close the tab, then again double click Visualization Manager to open it again and view the settings.

CODESYS automatically transfers fonts to the device providing the user accepts this process when requested to do so by CODESYS. Where device memory is fully utilised, user options are available to help minimise the amount of memory occupied by fonts.

Double Click  Visualization Manager in the project tree and select the  Font settings tab to see the option:




Parameter	Description																																																																																																																								
Character Settings for Font Download	<p>No Font Download: (Not Recommended) No font is sent to the device. CODESYS selects a basic, default font for all text. This may not match the shape and/or size of the required text.</p> <p>Download of Minimal Character Set: All characters used in the visualisation are downloaded to the device. However, any characters not used in the visualisation but used in variables (ie Strings) are NOT sent to the device. To 'force' characters to be sent to the device:</p> <ul style="list-style-type: none"> • Use a hidden visualisation page containing all the font/character selection required for the application. • Use <i>Download of Character Set Ranges</i>. <p>Download of Character Set Ranges: The user selects which character range or ranges to send to the device. Windows Character Map is a useful tool for identifying the range(s) of characters you may need.</p> <p>Adding the range <i>U+0021-U+00B0</i>;</p>  <p>ensures that most used characters are sent to the device (a to z, A to Z, 0 to 9 and many punctuation characters):</p> <table border="1" style="margin: 10px auto;"> <tr><td>!</td><td>"</td><td>#</td><td>\$</td><td>%</td><td>&</td><td>'</td><td>(</td><td>)</td><td>*</td><td>+</td><td>,</td><td>-</td><td>.</td><td>/</td><td>0</td><td>1</td><td>2</td><td>3</td><td>4</td></tr> <tr><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>:</td><td>;</td><td><</td><td>=</td><td>></td><td>?</td><td>@</td><td>A</td><td>B</td><td>C</td><td>D</td><td>E</td><td>F</td><td>G</td><td>H</td></tr> <tr><td>I</td><td>J</td><td>K</td><td>L</td><td>M</td><td>N</td><td>O</td><td>P</td><td>Q</td><td>R</td><td>S</td><td>T</td><td>U</td><td>V</td><td>W</td><td>X</td><td>Y</td><td>Z</td><td>[</td><td>\</td></tr> <tr><td>]</td><td>^</td><td>_</td><td>`</td><td>a</td><td>b</td><td>c</td><td>d</td><td>e</td><td>f</td><td>g</td><td>h</td><td>i</td><td>j</td><td>k</td><td>l</td><td>m</td><td>n</td><td>o</td><td>p</td></tr> <tr><td>q</td><td>r</td><td>s</td><td>t</td><td>u</td><td>v</td><td>w</td><td>x</td><td>y</td><td>z</td><td>{</td><td> </td><td>}</td><td>~</td><td></td><td>ı</td><td>¢</td><td>£</td><td>¤</td><td>¥</td></tr> <tr><td>ı</td><td>§</td><td>¨</td><td>©</td><td>ª</td><td>«</td><td>¬</td><td>-</td><td>®</td><td>¯</td><td>°</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr> </table> <p>Download of Complete Fonts: (Most commonly selected option). The complete character set of all used fonts is sent to the device occupying a larger amount of memory in the device.</p>	!	"	#	\$	%	&	'	()	*	+	,	-	.	/	0	1	2	3	4	5	6	7	8	9	:	;	<	=	>	?	@	A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z	[\]	^	_	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o	p	q	r	s	t	u	v	w	x	y	z	{		}	~		ı	¢	£	¤	¥	ı	§	¨	©	ª	«	¬	-	®	¯	°									
!	"	#	\$	%	&	'	()	*	+	,	-	.	/	0	1	2	3	4																																																																																																						
5	6	7	8	9	:	;	<	=	>	?	@	A	B	C	D	E	F	G	H																																																																																																						
I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z	[\																																																																																																						
]	^	_	`	a	b	c	d	e	f	g	h	i	j	k	l	m	n	o	p																																																																																																						
q	r	s	t	u	v	w	x	y	z	{		}	~		ı	¢	£	¤	¥																																																																																																						
ı	§	¨	©	ª	«	¬	-	®	¯	°																																																																																																															

5.6.2 USING CUSTOM IMAGES


Many applications require custom images to be placed on the DSEM840 display. This is controlled using an *Image Pool* within CODESYS. The Image Pool acts as a container for the images, which are then selected for display.

5.6.2.1 ADDING AN IMAGE POOL

NOTE: Multiple *ImagePools* can be utilised to better manage images.




5.6.2.2 ADDING IMAGES TO THE IMAGE POOL




Continued overleaf...


Connecting to CODESYS



Right-Click the empty line and select *Insert Image*.



Then Double-Click the empty space under *File name* and click ...




Browse to the image on your computer...



And select how the image is stored in the project.

Click *OK* when done.

NOTE: Ensure the *ID* in the image pool contains only alphanumeric characters, - (minus), and _ (underscore). Many other characters, including ' ' (full stop) and spaces are not supported and may result in the image not appearing on the display.




Example entries in the *Image Pool*.

ID	File name	Image	Link type
DSE	DSE.jpg		Embedded
CONTROL	control.PNG		Embedded

5.6.2.3 USING THE IMAGE POOL ON THE DISPLAY

Entries within the Image Pool are automatically detected by the CODESYS Visualisation Toolbox and are available for placing on the Visualisation.



Select *Image Pool* in the Visualisation Toolbox

Example entries in the *Image Pool* ready for placing on the Visualisation.

5.6.2.4 IMAGE TRANSPARENCY

NOTE: Ensure the use of a solid *transparency* colour in the images. The graphical application functionality and the use of compressed images may change individual pixel colours within a block of solid colour

CODESYS provides a method to select a colour within each individual image to be treated as *transparent* across all images used in the application.

For example,

The image illustrates the steps to enable transparency for an image in the CODESYS Visualization environment. It consists of two screenshots of the software interface, with callout boxes providing instructions.

Top Screenshot: Shows a visualization window with a purple image containing a semi-circular pattern. The Properties window is open, showing the following table:

Property	Value
Element name	GenElemInst_1
Type of element	Image
Static ID	ImagePool.Meter_Quad_8
Show frame	<input type="checkbox"/>
Clipping	<input type="checkbox"/>
Transparent	<input type="checkbox"/>
Transparent color	Black
Scaling type	Anisotropic

A callout box points to the image with the text: "Add the image from the ImagePool".

Bottom Screenshot: Shows the same visualization window, but the image is now semi-transparent, revealing the underlying pattern. The Properties window is open, showing the following table:

Property	Value
Element name	GenElemInst_1
Type of element	Image
Static ID	ImagePool.Meter_Quad_8
Show frame	<input type="checkbox"/>
Clipping	<input type="checkbox"/>
Transparent	<input checked="" type="checkbox"/>
Transparent color	128, 0, 255
Scaling type	Anisotropic

Two callout boxes point to the Properties window: "Enable transparency for this image" points to the 'Transparent' checkbox, and "Click ... and select the colour or enter the values for R, G, and B manually" points to the 'Transparent color' field.

5.7 USING PERSISTENT VARIABLES IN THE PROJECT

NOTE: M840-01 only: Ignition (Pin A13) must be utilised correctly to enable / disable the application program. This ensures that *Persistent Variables* (e.g., logs and other changed parameters) and other files are saved correctly. Incorrect device shutdown while using the file system may result in loss of Application Program.

Variables placed in a Persistent Variables object are stored at regular intervals and maintained when the device is powered off. The variables are automatically loaded when the device powers up.

Right Click Application

Select Add Object...

Select Persistent Variables...

To add variables, double click the new object in the project tree.

Example variables

```

1 {attribute 'qualified_only'}
2 VAR_GLOBAL PERSISTENT RETAIN
3   MyNewVariable      : INT;
4   MyNewArray         : ARRAY[0..7] OF DINT;
5 END_VAR
    
```

Within the POU the variables are address as normal. In this example we've named the object *PersistentVars* however any IEC compatible name can be used. Multiple *Persistent Variable* objects can be used as required.

Example:
 PersistentVars.MyNewVariable:=2512;
 PersistentVars.MyNewArray[2]:=32167;

5.8 APPLICATION UPDATE


While a live CODESYS connection to the device by Ethernet is the most common method to load the application, alternatives exist as detailed below. Both options require the creation of a 'Boot Application' and the use of *DSEServiceTool PC Software*. First, we must connect by Ethernet to a device to create the .pkg file.

5.8.1 CREATION OF THE BOOT APPLICATION AND .PKG FILE

NOTE: For further details using DSEServiceTool PC Software see DSE publication 057-265 *DSE ServiceTool PC Software Manual*.

NOTE: The boot application includes the folder *PicLogic*. This contains all images, text files and associated visualisation files.

Within CODESYS select *Online | Create boot application*




Browse to select the location to store the files. It is convenient to put the file (application.app) into an empty folder.

Within DSEServiceTool PC Software scan for and select the DSEM840 device, then select the file *Application.app* and transfer it to the DSEM840.

The process of transfer creates *Application.pkg* and stores it along with the *Application.app* file.

With the .pkg file now created, this can be used to update other devices by USB if required.

5.8.2 APPLICATION UPDATE USING USB

 **NOTE:** A **.pkg** (package) file of the application must be pre-prepared as described in the section entitled *Creation of the Boot Application and pkg file* elsewhere in this document.

 **NOTE:** The **.pkg** file is a compressed folder, containing all images, text files and associated visualisation files.

- Store the .pkg file on a USB memory stick.
- Remove ECU Power from the device.
- Press and hold any THREE buttons.
- Apply ECU Power.
- Wait until the display enters the Boot Menu and release the three buttons.
- Connect the memory stick to the device USB connection using the M12 to USB-A adaptor.
- Use ◀ ▶ ▲ ▼ and **OK** to navigate the USB device file structure and select the .pkg file to apply.
- Press **OK** to install the file.
- After confirmation, remove DC Supply from the device.
- Remove the USB memory stick.
- The update is complete.

5.9 PROGRAMATIC FILE ACCESS

NOTE: Within a CODESYS STRING, the \$ character is used as an *escape* character. To add \$ as a 'usable' character within a STRING, use \$\$. ie myString:='The price is \$\$50';

DSEM840-02 has an internal filing system accessible using the *SysFile* library. This is useful for storing data not suitable for the *Persistent Variables* storage. In addition to the storage in device memory the filing system includes support for USB memory devices.

Location	Path	Usage In CODESYS STRING	Example
M840-02 Internal File System	\$lecFilePath\$		sFilename:='Test.csv'
M840-02 External USB File System	\$usb\$	\$\$usb\$\$\	sFilename:='\$\$usb\$\$\Test.csv'

Example:

```
// Open the file and get the handle
hFile := SysFileOpen(szFile:= '$$usb$$\Test.csv', am := AM_WRITE, pResult := ADR(eResult));
```

5.9.1 BROWSING THE FILE SYSTEM USING CODESYS

You can view and copy files to/from the M840 filesystem using the CODESYS File Browser as shown below.

The image shows a screenshot of the CODESYS environment. On the left, the project tree for 'M840MKII_MultiDemoV4' is visible, with 'Device (M840)' selected. A callout box points to 'Device (M840)' with the text: 'Double Click Device in the project tree.' Below the project tree, the 'Device' File Browser window is open, showing two panes: 'Host' (PC File System) and 'Runtime' (DSEM840-02 File System). The 'Host' pane shows the local file system with drives C:\, D:\, and E:\. The 'Runtime' pane shows the device's file system with folders like PkgLogic, \$log\$, \$usb\$, and \$ecFilePath\$. A callout box points to the 'Refresh' button in the Runtime pane with the text: 'Click Refresh to update the file list'. Another callout box points to the 'Files' section in the Host pane with the text: 'Within Device, select Files'. A third callout box points to the transfer arrows between the panes with the text: 'Transfer files from PC to device and vice versa'. A fourth callout box points to the 'Runtime' pane with the text: 'DSEM840-02 File System'. A fifth callout box points to the 'Host' pane with the text: 'PC File System'.

5.10 ALTERNATIVE METHODS TO LOAD THE APPLICATION

NOTE: To transfer an application to the device using USB, a .pkg file must first be created using DSEServicetool PC Software as described below.


While a live connection to the device by Ethernet is the most common method to load the application, alternatives exist as detailed below. Both options require the creation of a 'Boot Application' and the use of *DSEServicetool PC Software*. First, we must connect by Ethernet to a device to create the .pkg file.

5.10.1 CREATION OF THE BOOT APPLICATION

NOTE: For details using DSEServicetool PC Software see DSE publication *057-265 DSE Servicetool PC Software Manual*.


NOTE: The boot application includes the folder *PlcLogic*. This contains all images, text files and associated visualisation files.

Within CODESYS select *Online | Create boot application*



Browse to select the location to store the files. It is convenient to put the files into a new (empty) folder. The example, to the right shows the boot application files in the new folder.

All these files (including the sub folder) make up the boot application and must be kept together.




Continued overleaf.

5.10.2 UPDATE USING DSESERVICETOOL AND ETHERNET CONNECTION

NOTE: For details using DSEServicetool PC Software see DSE publication 057-265 *DSE Servicetool PC Software Manual*.





Within DSEServicetool PC Software scan for and select the device, then select the file *Application.app* and transfer it to the device. The process of transfer creates *Application.pkg* and stores it along with the *Application.app* file.



5.10.3 UPDATE USING USB

Store the .pkg file AND PlcLogic folder complete with contents on a USB memory stick

- Remove ECU Power from the device.
- Press and hold any THREE buttons.
- Apply ECU Power.
- Wait until the display enters the Boot Menu and release the three buttons.
- Select *Load From USB* and press *OK* to view the list of files on the USB device.
- Select the application from the list using *Up*, and *Down* buttons and press *OK* to select.
- When prompted, confirm the update by selecting *Yes* and press *OK* to continue.
- Wait for the process to complete....
- *Upload Complete* is shown on the display upon completion.
- Press *ESC* to return to the file list.
- Select another package if required or Press *ESC* to return to the main menu.
- From the main menu, select *Restart* and press *OK*. The device restarts and the new package is applied.



5.11 USING NETWORK VARIABLES IN THE PROJECT

NOTE: M840 supports a maximum of 5 (five) BYTES to be transferred by Network Variables.

NOTE: Sender and Receiver Network Variable Lists MUST match.

NOTE: A suitable M12 to RJ45 cable is DSE Part 016-160.

Network Variables are a special type of Global Variable List and allow multiple devices to share a common variable list, utilising Ethernet (UDP) to communicate. To facilitate this, the simplest method of connection is to utilise a generic ethernet network switch as shown below. Whilst it is possible to connect two devices by a single M10 to M10 ethernet cable, the below method also provides for connection of the PC to another port of the network switch.



One device is the *Sender*, with other devices being a *Receiver*. The variable list from the application of the sender is exported to allow the receiver applications to receive them.

5.12 USING CAN IN THE PROJECT

NOTE: DSEM840 has two CAN ports. Referred to as *Network0* and *Network1*. With DSE_CAN library the enum *DSE_CAN.eCANList.CAN1* and *DSE_CAN.eCANList.CAN2* can be used.

NOTE: DSE_CAN compiled library, supplied as part of the DSE CODESYS Package is available from www.deepseaelectronics.com.

CAN Protocol	Options
SAE J1939	<ul style="list-style-type: none"> • CODESYS J1939 (see section entitled <i>CODESYS J1939</i>) • DSE_CAN compiled library
Raw CAN (custom protocols)	<ul style="list-style-type: none"> • DSE_CAN compiled library
CANopen	DSEM840 supports CODESYS CANopen Manager driver, enabling DSEM840 to connect to CANopen slaves.
Other CAN protocols	Contact support@deepseaelectronics.com

5.12.1 DSE_CAN

NOTE: DSEM840 has two CAN ports. Referred to as *Network0* and *Network1*. With DSE_CAN library the enum *DSE_CAN.eCANList.CAN1* and *DSE_CAN.eCANList.CAN2* can be used.

DSE_CAN compiled library, supplied as part of the *DSE CODESYS Package* available from www.deepseaelectronics.com allows standard CAN messages to be sent and received. This may be used (with customer application code) to interface with J1939, custom protocols and other CAN protocols as required.


While CODESYS Library Manager includes help for the libraries, for additional information, contact support@deepseaelectronics.com.

5.12.2 CODESYS J1939

NOTE: DSEM840 has two CAN ports. Referred to as *Network0* and *Network1*. With DSE_CAN library the enum *DSE_CAN.eCANList.CAN1* and *DSE_CAN.eCANList.CAN2* can be used.


CODESYS J1939 is a complete J1939 implementation for sending and receiving J1939 CAN messages. Conversion to/from actual values and CAN data is automatic (when enabled).

First add the CAN device to the project:




Keep the *Add Device* window open.

Connecting to CODESYS



Select the CANbus device in the project tree




Select J1939 Manager

And add it to the project

DO NOT close the window yet.....

Keep the *Add Device* window open.



Select the J1939_Manager device in the project tree

Connecting to CODESYS

Add J1939 ECU to the project.

And add to it the *J1939_Manager* from the *add Device* window.

Close Window

NOTE: DSEM840 has two CAN ports. Within the CODESYS CAN device, set *Network* to 0 for CAN 1, and set *Network* to 1 for CAN 2.

Double Click the CANbus device.

Select the *General* tab

Ensure correct *Network* (0 or 1)

Set *Baudrate* as required.

The project is now able to communicate with one J1939 ECU. Other devices may be added as required to allow communication with other J1939 ECUs on the same CAN.

For further information, please contact support@deepseaelectronics.com.


5.13 UNSUPPORTED CODESYS VISUALISATION ITEMS

The following CODESYS Visualisation items are **not** supported by DSEM840. This list is not exhaustive.

- Web Browser
- DataSource
- Trace
- Alarm Manager

6 DSEM840 CODESYS ERROR CODES

DSEM840 returns error codes to CODESYS when appropriate. Individual bits are set within the returned value to indicate one or more error conditions. This can be mapped to a variable if required and is available to view within CODESYS under the *Device Settings I/O Mapping* as shown below.



Examples:

A *Device* error value of 120 (01111000 in binary) indicates that all four *Output Supplies* are *Under Voltage*.

A *Device* error value of 2 (0000010 in binary) indicates *Over Temperature*.

6.1 DEVICE

MSB 8	Bit						LSB 1
	7	6	5	4	3	2	1
Output Reference Outside Limits	Reserved	Reserved	Reserved	Reserved	Under Voltage Supply	Over Temperature	Error

6.2 ANALOGUE INPUTS

Input Configuration	MSB 8	Bit						LSB 1
		7	6	5	4	3	2	1
Digital	Invalid Parameter	Reserved	Reserved	Invalid Threshold	Reserved	Reserved	Reserved	Error
Voltage	Invalid Parameter	Reserved	Reserved	Reserved	Reserved	Over Range	Inverted Input (<10 mV)	Error
Current	Invalid Parameter	Reserved	Reserved	Reserved	Reserved	Over Range	Wire Break (<4 mA)	Error
Resistance	Invalid Parameter	Reserved	Reserved	Reserved	Reserved	Over Range	Reserved	Error
Ratiometric	Invalid Parameter	Reserved	Invalid Reference	Reserved	Reserved	Over Range	Reserved	Error

6.3 DIGITAL INPUTS

Input Configuration	Bit							
	MSB 8	7	6	5	4	3	2	LSB 1
Digital	Invalid Parameter	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Error
Frequency	Invalid Parameter	Reserved	Reserved	Reserved	Reserved	Freq Over Range	Reserved	Error

6.4 DIGITAL OUTPUTS

Output Configuration	Bit							
	MSB 8	7	6	5	4	3	2	LSB 1
Digital	Invalid Parameter	Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Error

7 FIRMWARE UPDATE

 **NOTE: Firmware update is also possible using DSEServiceTool PC Software. For further details, see DSE publication 057-265 DSE ServiceTool PC Software Manual.**

- Store the update .pkg file on a USB memory stick.
- Remove ECU Power from the device.
- Press and hold any THREE buttons.
- Apply ECU Power.
- Wait until the display enters the Boot Menu and release the three buttons.
- Connect the memory stick to the device USB connection using the M12 to USB-A adaptor.
- Use ◀ ▶ ▲ ▼ and **OK** to navigate the USB device file structure and select the .pkg file to apply.
- Press **OK** to install the file.
- After confirmation, remove DC Supply from the device.
- Remove the USB memory stick.
- The update is complete.

8 CABLES, CONNECTORS, HARNESSES AND SPARE PARTS

Description	DSE Part	Manufacturer Part	Manufacturer
DSEM840 Connector A	007-850	DT16-18SA-K004	TE / Deutsch
Connector Pin Crimp (0.5 mm ² to 1.0 mm ²)	N/A	0462-201-16	TE
Connector Pin Crimp (2 mm ²)		0462-209-16	TE
DSEM840 Connector Harness Kit	016-168	N/A	DSE
M12 to Ethernet Cable	016-160	VS-M12MS-IP20-93R-L1/2	Phoenix
M12 to USB Cable	016-161	N/A	DSE
Belden 9841 (CAN Cable)	016-030	9841	Belden
Panel Mounting Sealing Gasket	020-602	N/A	DSE





8.1 DSEM840 CONNECTOR HARNESS KIT (016-168)

DSE Part 016-168 consists of a cable with connector fitted at one end, with cable marking to identify the wires at the other end.

	Connector A
Assembly Ident	007-850
AMP Connector	DT16-18SA-K004
No of Connections	18
Wire size	0.5 mm ² (AWG 20)
Wire Colour	Black
Wire Idents	1 to 18
Connector Pin Crimp (0.5 mm ² to 1.0 mm ²)	0462-201-16
Connector Pin Crimp (2 mm ²)	0462-209-16

9 TROUBLESHOOTING

The below are suggestions answering frequently questions about the device.

Symptom	Suggestion
<p>Error message after transferring the application to the controller by CODESYS:</p>  <p>Viewing the <i>Messages View</i> shows:</p> 	<p>This occurs where a later version of CODESYS is present on the PC and IOSTANDARD library within the project is a later version than supported by DSEM840 (which supports up to CODESYS 3.5.12.0).</p> <p>To correct this, open Library Manager in the project and locate <i>IOStandard</i> Library. <i>Right Click</i> it and select <i>Properties</i>. Then select <i>Specific Version</i> and enter 3.5.10.0 :</p>  <p>It now appears correctly in the Library Manager :</p> 
<p>Text on the display differs from that selected.</p>	<p>This occurs where the selected font character is not present on the device, the <i>default</i> font is selected.</p> <p>For further details, see section entitled <i>Connecting to CODESYS Using the Display in the Project Installing Fonts</i>.</p>
<p>Images are not appearing on the device display.</p>	<ul style="list-style-type: none"> • See section entitled <i>Using Custom Images on the Display</i> elsewhere in this document. • Ensure the ID in the image pool contains only alphanumeric characters. • It is possible that the device memory is full and there is no room for more images. To ensure existing, unneeded files are not present, format the device before deploying
<p>How do I use Persistent Variables?</p>	<ul style="list-style-type: none"> • Add a Persistent Variables object to the project. Right Click <i>Application</i> and select <i>Add Object Persistent Variables</i>. Variables placed here are stored as selected above and persist through a power off. See section entitled <i>Using Persistent Variables in the Project</i> elsewhere in this document.
<p>How can I connect an RTD temperature sensor or thermocouple</p>	<p>DSEM840 Resistive Inputs are accurate to 1 % of full measurement scale (3400 Ω). This makes RTDs unsuitable for connection to DSEM840. Suggested alternatives are:</p> <ul style="list-style-type: none"> • Temperature sensors with a 0 V to 5 V, 0 V to 10 V, or 4 mA to 20 mA output across the range of temperatures to be measured. • DSE2170 RTD and Thermocouple expansion. • Sensors with CAN support are suitable.

10 MAINTENANCE AND WARRANTY

The device is *Fit and Forget*. As such, there are no user serviceable parts within the controller. In the case of malfunction, you should contact your original equipment manufacturer (OEM).

DSE Provides limited warranty to the equipment purchaser at the point of sale. For full details of any applicable warranty, refer to the original equipment supplier (OEM).

11 DISPOSAL

11.1 WEEE (WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT)

If you use electrical and electronic equipment you must store, collect, treat, recycle and dispose of WEEE separately from your other waste



This Page is Intentionally Blank